


Manual

(Read me please 😊)


What's in the box



strap-on massager x1



Remote controller x1
(in the right-side pocket)



Balloons x3




Strap-on mode



T-Rex mode

How it works?



**squeeze your muscles like
a pro masseur**

*We have balloons in the package, feel free to use it if
you want to make a viral video with it*


Step 1

Charge it before use



Compatible with any of your USB
Type-C adapter

Power adapter is not included in this package



Long press 3s to turn on/off



3 Massage Modes

Mode 1: Pinch Clockwise

Mode 2: Pinch Counter-Clockwise

Mode 3: Pinch Intermittently



2 Heat levels

Level 1: Mild heat

Level 2: A bit hot, yet still soothing



3 Speeds



Long press 3s
to turn on/off




3 Massage Modes

Mode 1: Pinch Clockwise

Mode 2: Pinch Counter-Clockwise

Mode 3: Pinch Intermittently



2 Heat levels

Level 1: Mild heat


Level 2: A bit hot, yet still soothing



3 Speeds

Feel more relaxed with Remote


Long press 3s to turn on/off




Check Orientation

Avoid using it upside-down


Left side



Right side



10 mins timer




Just restart massager after the timer ends if you can't get enough of it

Trouble-shooting

For most of the problems:

1. Turn off the massager, and let it cool down
2. Charge the massager and try again



If the problem cannot be solved, please email

service@chilltreat.us

for help. We'd love to make you 100% satisfied

Disclaimer

- Disconnect the power plug after use or before cleaning.
- Avoid using this machine in damp environments or bathrooms.
- Store it in a dry area away from direct sunlight after each use.
- Refrain from using it while sleeping to prevent prolonged stimulation of specific areas that may affect health.
- Avoid using the massage machine within thirty minutes after meals, as it may have adverse effects depending on individual body constitutions. If discomfort arises from excessive stimulation during use, discontinue immediately.
- Ensure that suitable tutors are present to guide children or individuals with limited physical freedom when using this product. Individuals experiencing conditions such as pregnancy, spinal pain, acute illness, or heart disease should use it under the guidance of a doctor.
- After a massage session, consume 500cc of plain water or hot tea to promote the excretion of metabolic substances from the body.
- In case the power cord is damaged, consult us for a replacement of the dedicated power cord for household use or contact the manufacturer.
- Avoid using this product if you have physical disabilities, sensory or mental impairments, or lack relevant experience and knowledge, unless supervised by someone responsible for safety.
- Ensure children are supervised to prevent them from playing with the device.
- Note that the device includes a heating surface
- Avoid placing the massager in direct sunlight or high temperatures while in the car to prevent potential hazards or damage to personal property

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF exposure:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.