








|  |   |  |  |  |   |
|--|---|--|--|--|---|
| What's in the Box?   | Remove your speaker from its packaging  | Get to know your speaker   | Basic Operation  | Charge your speaker  | Connect your speaker to your device   |
|  <p>1 - TRUTH45 Speaker<br/>2 - USB-A to USB-C Charging Cable<br/>3 - Quick Start Guide</p> |  <p>Remove your speaker by gripping each side of its waist, putting pressure down on the black protective packaging, and pulling the speaker out</p> <p>Your speaker's electronic components are in its brown base, and your speaker's arms could break if you grip and pull them. That's why we recommend removing the speaker by the waist.</p> |  <p>1 - Power<br/>2 - Volume Down<br/>3 - Volume Up<br/>4 - USB-C Charging Port</p> |  <p>1. Press and hold Power button for 2 seconds to turn your speaker on or turn it off<br/>2. Short press of Volume Up button increases volume<br/>3. Short press of Volume Down button decreases volume</p> |  <p>Please fully charge your speaker before first use.</p> <p>1. Plug the USB-A end of your charging cable into a charger (not included)<br/>2. Plug the USB-C end of your charging cable into your speaker's charging port</p> |  <p>1. Press your speaker's power button for a second<br/>2. Your speaker tells you it's in pairing mode<br/>3. Open your device's pairing settings and connect to TRUTH45</p> |

|   |
|---|
| Speak Out TRUTH45 Speaker<br><br>Model: TRUTH45-1 |
|   |

|   |   |  |  |  |  |
|---|---|--|--|--|--|
| Pair two Speak Out speakers as Right and Left Channels  | Other Features  | Other Features   | Safety and Use   | FCC Warning  | FCC Warning  |
| <p>1. Turn one of your speakers on<br/>2. Pair your speaker with your device<br/>3. Press Power button twice on your paired speaker<br/>4. Your speaker tells you it's searching for another speaker to pair<br/>5. Turn on your second Speak Out speaker<br/>6. The first speaker tells you it's the right channel speaker<br/>7. The second speaker tells you it's the left channel speaker</p> |  <p>1. A short press of Power button plays or pauses your audio<br/>2. A press of 8 seconds of Power button resets your speaker</p> |  <p>1. Press and hold Volume Down button to go to previous track<br/>2. Press and hold Volume Up button to go to next track</p> | <p>1. Store and use equipment in a room temperature environment. Do not place this equipment in an environment with an ambient temperature higher than 70°C or lower than -20°C for an extended period of time.<br/>2. Do not charge or use the equipment in rain or high humidity environments.<br/>3. Do not charge or use this equipment in or around water.<br/>4. Keep this equipment away from open flames and heat sources.<br/>5. Do not disassemble, repair and / or transform the equipment.<br/>6. This product has a built-in lithium battery. Do not throw it away. Properly dispose of the equipment at a recycling point equipped to accommodate lithium batteries or at a household hazardous waste collection point.<br/>Note: If you violate the above warnings and use the equipment improperly, you bear all responsibility for any personal and property damage. The company will bear no legal responsibility.</p> | <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:<br/>- Reorient or relocate the receiving antenna.<br/>- Increase the separation between the equipment and receiver.<br/>- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.<br/>- Consult the dealer or an experienced radio/TV technician for help.</p> | <p>Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.</p> <p>The device has been evaluated to meet general RF exposure requirement. To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation.</p> |