


# Body fat scale manual

## One. OKOK APP Downloading

Downloading body finger scale APP There are several ways:  
1. scan two-dimensional code download



## Two. APP install



## Three. Open APP registration information


1. The registration information can be completed in the following ways
2. 1, login the number of the mobile phone number
3. 2. Log in with QQ, WeChat, mailbox account



## Four. Connect Bluetooth

1. Open Bluetooth on the phone

Click on the "Bluetooth Intelligent Scale", jump out of the following interface, people can be on the body fat scale, such as body fat scale lock the current weight, mobile phone APP terminal will appear the following interface, click "to determine the binding."



## Five. Enter the APP function interface and automatically synchronize data after measurement.



## FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.