

ILOCKZONE

LC-30




1

User Manual

2

3. Operations

• Functional Guide



Tips:

The volume of the headset can be adjusted via the headset button and your phone. If you still feel the volume is too low or too loud in one of these two ways, you can adjust it in another way to get the proper volume.

• Charging the Headset

The built-in battery is rechargeable and please use the included Type-C cable to charge the headset by connecting to a USB port of your computer, powerbank or into an USB AC adapter (requires 5VDC). Turn off the headset before charging, while charging, the RED light stays on. Once fully charged, the red light will go off.

• Power On

When the headset is off, press and hold the MF button about 3 seconds until you hear 'power on', and you will see the blue light stays on.

• Power Off

When the headset is on, press and hold the MF button about 3 seconds until you hear 'power off', and you will see red light flash, then go off.

• Pairing & Connection

When the headset is off, press and hold the MF button about 3 sec until the blue & red light blinks alternately. The headset enters pairing mode. Turn on Bluetooth function of your device (phone) and select 'search' or 'discovery' devices, then select 'ILOCKZONE LC-30' from the list, the headset will be connected to your phone. If requested, type the password or pin '0000'. If the Bluetooth on your device (phone) remains on, the headset will be connected automatically when you restart it next time. No need to pair again.

• Answer/Reject/Hang up

When a call is coming, press the MF button once to answer the call and press it again to end the call. When a call is coming, press and hold the MF button 2 seconds to reject the call.

• Volume Adjustment

Make sure the headset is connected to your phone. Press the volume up '+' you will hear the volume going up. Press the volume down '-' you will hear the volume going down.

• Play/Pause

Make sure the headset is connected to your phone. When playing music, Press the MF button once to pause, press again to play.

• Previous/Next Song

Make sure the headset is connected to your phone. When playing music, Press and hold the volume up '+' button to play next song, Press and hold the volume down '-' button to play previous song.

• ANC On

When the headset is on, press the ANC ON/OFF you hear 'anc on', and you will see the green light stays on.

• ANC Off

When the headset is on, press ANC ON/OFF you hear 'anc off', and you will see green light will go off.

4. Specifications

Item : ANC Bluetooth Headphones

Bluetooth specification : Bluetooth V5.4

Battery Capacity: 800mAh

Work voltage: 3.7v

Working time: > 100h

Charging time: 2.5h

Charging Voltage: DC5V

Speaker diameter: φ40mm

Speaker frequency range: 20–20kHz

Speaker impedance: 32Ω

Sensitive: 115dB

6

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.