



Doorbell

Get alerts and capture images of every visitor




User Manual 1.0


Features



5. Doorbell Button




6. Reset Button



8. Type-C Port(Battery Charging)

9. Security screw hole

Indicator Light



Flashing RED




Flashing RED and BLUE alternately




Low battery. Please recharge the device.

In the box



Doorbell



Tape



Chime
(Optional)



USB Cable
(Optional)




3 Screws



2 Anchors

Charge the Doorbell

Fully charge the doorbell by a 5V1A USB charger and a Type-C USB cable. It takes about 10 hours to fully charge.




WARNING: Lots of events

If you have excessive number of visitors, you might need to charge it sooner.


Install your Doorbell

Mark drill holes and use a bit to drill holes in your wall. Insert anchors and secure your doorbell with mounting and security screws.

Step 1



Step 2




Set up your Wireless Chime (Optional)

Connect the doorbell to the doorbell chime, and get instant alert in your home when someone rings the doorbell. The chime plugs into any 5V USB port, you can place it anywhere in the home.


NOTICE:

The doorbell is only compatible with our wireless chime, and not compatible with traditional doorbell chimes. The wireless chime is optional. If it is not installed, doorbell notifications will still go directly to the Kement


The Basics



LED indicator
Speaker



Front



Pairing button


Back

Side

Set up your Wireless Chime

Step 1

Before the setup process, make sure your doorbell is on, then plug the chime into the USB port and it's ready to use.



Step 2

Press the pair button.



Set up your Wireless Chime


Step 3

Press the Doorbell Button for pairing.



Step 4

Press the Doorbell Button again to verify the chime and doorbell work properly.



* Volume of chime is not adjustable

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.