




Thank you for using this product,
please read this book carefully before use




Instructions for use



Product introduction



Long press on/off for 3 seconds,
short press switching frequency,
10 frequency cycle



Frequency frequency key


1: Short press to switch the
vibration mode,
A total of ten frequency
sequential cycle

Switch key

1: Short press to open the
main body function
2: Long press the main
body for standby

Charging instructions:

- 1 . Connect the USB
charging cable, and the
indicator light flashes.
- 2 . The product does not
work when charging, and
the full lights are on.
- 3 . Fill for about 90
minutes and work for
4575 minutes.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction