


# UHF wireless microphone

## User's Manual

### Receiver Function Description



1.6.5mm Plug

2. Switch


3. Work indicator light

4. Charge hole

### Operation and usage methods

1. Insert the receiver into the microphone input of the speaker or amplifier
2. Turn on the power switch of the receiver
3. Turn on the handheld microphone (insert two No. 5 batteries)
4. Turn on the power of the receiver, and the frequency indicator light of the receiver will remain on, The receiver and handheld microphone have been successfully connected.

### Handheld Launch Function Description



① Do not enter the menu to increase the volume key. Enter the menu to switch between A/B channels.

② Short press to enter the menu and switch frequencies, press  $\Delta/\nabla$ . Frequency can be adjusted. Press and hold for 3 seconds to enter the menu and switch between A/B frequency bands. Press  $\Delta/\nabla$  Can switch between A/B channels.

③ Do not enter the menu as the volume down button. Enter the menu to switch between A/B channels.

④ Power button function: Long press to turn on, long press to turn off. Shutdown status, Simultaneously press ① and ④ It will reset to the first frequency.

Power switch control display: Long press to turn on the device displays "ON" and "Long press to turn on the device displays" OFF "

Note: After switching A/B channels and restarting, press and hold the power button to display SET. Release your hand and the ID code will be automatically paired.

### Specifications

1. Frequency range: 652MHz-663MHz
2. Modulation: Digital frequency modulation
3. Frequency response: 75Hz~18KHz±3dB
4. Signal to Noise Ratio >90decibel
5. Distort: ≤1.0%@1KHz
6. Output level: 200mV±5mV
7. Pick Mode: Mobile coil type
8. Receiver power: lithium battery
9. channels: 16 of them

### After sales Service Warranty Instructions

1. Electronic performance warranty for transmitters and receivers. External accessories are not covered by the warranty.
2. The receiver battery is not covered by the warranty.
3. Artificial damage, wear and aging are not included in the warranty period.

### Warranty card

model	purchasing date	Fault phenomenon	comment

### FCC Warning

#### FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.