

尺寸: 80×105mm

材质: 180g双铜

折叠方式: 风琴折

AFUOO User Manual

Wireless Microphone



W60 pro

PACKING LIST



NOTE: Supplied AA batteries are not rechargeable.

Power Source



The microphone requires 2 AA batteries for power.

The receiver requires 1 AA battery for power.

PAIRING




Power ON/OFF
STEP1:
Press and hold the on/off button for 2 seconds to switch the receiver on.

Power ON/OFF
STEP2:
Press and hold the on/off button for 2 seconds to switch the microphone on.

NOTE:
Both the microphone and receiver are switched off by long pressing the power button for 2 seconds.

CONNECTION INDICATOR(1)

Unconnected:





This light flashes white continuously.



M1 and M2 light flashes white continuously.

CONNECTION INDICATOR(2)

Connected:




NOTE:

1. The two microphones are not fixed to correspond to M1 or M2 on the receiver each time they are connected.

2. When only one microphone is connected, either M1 or M2 may be lit on the receiver, but only one will be lit.

MICROPHONE BATTERY INDICATOR




Battery Indicator

Working Time:
20 hours when the battery is fully charged.
Recommended 1.5V 2000mAh AA battery.

Light	Lighting form	Battery Level
	Green light always on	75-100%
	Yellow light always on	45-75%
	Red light always on	20-45%
	Red light flashing fast	10-20%

NOTE: The microphone will automatically switch off when the battery level of the microphone falls below 10%.

RECEIVER BATTERY INDICATOR




Battery Indicator

Working Time:
10 hours when the battery is fully charged.
Recommended 1.5V 2000mAh AA battery.

BAT	Lighting form	Battery Level
	Green light always on	75-100%
	Yellow light always on	45-75%
	Red light always on	20-45%
	Red light flashing fast	10-20%

NOTE: The receiver will automatically switch off when the battery level of the receiver falls below 10%.

THREE MODES



L+, L-, L0
Three Mode Indicator

Double-click the power button to cycle through the three modes.

L-, L0, L+, three modes are designed to cope with different power and type of audio input port.

With the receiver plugged into the audio input port and the microphone and receiver switched on, it is recommended to switch to different modes to meet your needs if the audio playback device has any of the following anomalies.

1. Strange noises
2. Volume too loud or too low
3. Distorted sound

Usually the 3.5mm audio input port corresponds to L+ mode; the 6.35mm audio input port corresponds to L0, L- mode.

There are many different devices on the market with different standards, so you can switch between L-, L0, and L+ modes to find the right one for you.

NOTE: Default L0 mode every time you power up.

SPECIFICATION

Item Model Number	W60 pro
Connection	2.4G Hz
Connector Type	6.35 mm Jack, 3.5 mm Jack
Microphone Powered	2 AA Battery (1.5V 2000mAh X2)
Receiver Powered	1 AA Battery (1.5V 2000mAh)
Microphone Capsule	Dynamic Microphone
Microphone Dimension	
Receiver Dimension	
Gross Weight	
Compatible Devices	
Warranty	12 Months

For any assistance, please Email us : afuoo@micspk.cn

CE FCC RoHS
Made in China
©20240901 1.0

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment