





— Sleep or nothing —

SOUNDS

| | |
|---------------------|--------------------|
| Heartbeat | White Noise x 3 |
| Barometric Pressure | Pink Noise x 3 |
| Speaker | Brown Noise x 3 |
| Fan | Fan x 3 |
| Water | Flowing Water x 3 |
| Cloud | Rain x 3 |
| Bowl | Singing Bowl x 3 |
| Bird | Birds Chirping x 3 |
| Flame | Campfire x 2 |



WHITE NOISE MODE

Slide the switch to the left to turn on the machine, default to white noise mode.


TF CARD MODE

Long press **II** button to switch to **TF card mode**.



9 TYPES OF WHITE NOISE

These 9 buttons represent 9 types of white noise. (Note: These 9 buttons only operate in white noise mode.)




BLUETOOTH MODE


Long press **II** button to switch to **Bluetooth mode**.



BLUETOOTH MODE

Turn on the Bluetooth on your phone, search for **"M01"** and connect to it, then you can play the sound from your phone.





LINK EARPHONES

Connecting earphones with a Type-C interface to the machine
enables you to listen to the sound privately without disturbing others.

Note: We only support earphones with analog signal functionality, not digital signal. Please verify your earphone model before use.



-off timer (30, 60, or 90 minutes)

shutdown, the power switch position, only switch it OFF then next use.

in charging, and it will turn charged.

phonemically retain the last sound

charged.



 support

www.mayogelco.com

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.