

SenseFlow

Essential Oil Diffuser User Manual

www.thesenseflow.com

Contents

- Safety Instructions 1
- Product Overview 2
- Specifications 3
- How to Use 3
 - Unpacking 3
 - Installing the Diffuser 3
 - Selecting Spray Output 3
 - Turning Off the Night Light 4
- Maintenance and Cleaning 4
- Troubleshooting 5
- Warranty and Support 6

Thank You for Choosing SenseFlow

This manual provides guidance on setting up, using, and maintaining your diffuser to ensure a long and enjoyable experience. Please read this manual before using the diffuser.

Safety Instructions

To ensure your safety and the proper use of this product, please strictly follow these warnings:

- Do not use the diffuser in damp or wet environments to avoid electrical short circuits or electric shocks.
- Do not place the diffuser on unstable surfaces to prevent tipping, which may cause essential oil leakage and electrical short circuits.
- Do not place the diffuser near high temperatures or open flames to prevent fire hazards.
- Keep the diffuser out of reach of children and pets to avoid accidents.
- Do not operate the diffuser without essential oil in the bottle to prevent damage to electrical components.
- Do not immerse any part of the diffuser in water or other liquids to avoid electric shocks or product damage.
- Do not disassemble, repair, or modify the diffuser yourself, as unauthorized actions may cause safety hazards.
- Do not use unspecified or unknown essential oils to avoid allergic reactions or damage to the diffuser.
- If you notice abnormal heating, smoke, or strange odors from the diffuser, immediately disconnect the power and stop using it. Contact a professional for inspection.
- If any liquid enters the electrical part, stop using it immediately and disconnect the power to avoid electric shock risks.

Product Overview





1. Mist Nozzle
2. Air Intake
3. Plug
4. Mist Indicator Light
5. Mist Button
6. Essential Oil Bottle Insert
7. Essential Oil Bottle
8. Cotton Swab
9. Support Bracket (Optional)

Specifications

Product Name	Aroma diffuser
Model	SF101
Dimensions	112x112x288 mm / 4" x 4" x 11"
Output Voltage	DC12V
Input Voltage	AC 100-240V
Power	10W
Essential Oil Capacity	30ml
Mist Levels	4
Night Light	Yes

How to Use

Remove the Packaging

1. Carefully take out the diffuser, essential oil bottle and all accessories from the packaging.
2. Check all parts to ensure there is no damage.

Preparing the Essential Oil Bottle

1. Twist the cap counterclockwise to remove it from the essential oil bottle. Then remove the plastic

stopper to open the bottle.



2. Insert the cotton swab into the essential oil bottle.



3. Align the cotton swab with the insertion point at the bottom of the diffuser, push the essential oil bottle up, and twist the bottle clockwise until you feel it is secure in place.



Installing the Diffuser

1. Insert the plug into a wall outlet.



2. Optionally, you can place the support bracket under the plug for better stability.



Selecting Mist Output

Repeatedly press the mist button:

1. First press: Low mist setting. The diffuser sprays essential oil mist every 10 minutes. Only the left indicator light is on.
2. Second press: Medium mist setting. The diffuser sprays essential oil mist every 6 minutes. Only the middle indicator light is on.
3. Third press: High mist setting. The diffuser sprays essential oil mist every 2 minutes. Only the right indicator light is on.
4. Fourth press: Max mist setting. The diffuser sprays essential oil mist every minute. All indicator lights are on.

Turning Off the Night Light

The night light turns on automatically. Press the mist button twice to turn off the night light.

Maintenance and Cleaning

Cleaning the Diffuser

1. Turn off and unplug the diffuser before cleaning.
2. Remove the essential oil bottle from the diffuser.
3. Wipe the exterior of the diffuser with a damp cloth.
4. Ensure all parts are completely dry before reassembling.

Safety Warnings

- 1. Do not immerse:** Never immerse the diffuser in water. This may damage electrical components and pose a safety hazard.
- 2. Avoid contact with water:** Ensure the plug does not come into contact with water to prevent electric shock or device damage.
- 3. Always place upwards:** Ensure the essential oil bottles and mist nozzles are facing upward to avoid essential oil spill.

Maintenance Tips

1. Regular cleaning: Clean the diffuser regularly as recommended by the manufacturer to maintain optimal performance.
2. Proper placement: Place the essential oil bottle on a stable surface to avoid tipping.
3. Use clean water: Always use clean water and high-quality essential oils to prevent residue buildup.

Troubleshooting

Common Issues	Solutions
Diffuser will not start	● Ensure the power plug is properly connected ● Check if the power outlet is functioning
No mist or reduced mist	● New diffusers may take one minute for the cotton swab to fully soak in the essential oil. Please allow a few minutes for the fragrance to start diffusing. ● Ensure there is enough essential oil in the bottle ● Select a higher mist setting
Unpleasant smell	● Clean the essential oil connector and use original or high-quality essential oils

If you encounter other issues or the problem persists, please contact customer support at: support@thesenseflow.com. We are always ready to help!

Warranty and Support

Warranty

- This product comes with a 3-year warranty from the date of purchase.
- The warranty covers defects in materials and workmanship under normal use.

Support

For any questions, troubleshooting, or warranty claims, please visit our official website www.thesenseflow.com or contact customer support at: support@thesenseflow.com

Thank you for choosing our aroma diffuser. We hope it brings a pleasant and relaxing atmosphere to your space.

Manufacturer/Importer: Guangzhou Zhigan Yuandong Technology Co., Ltd.

Address: Room 102, Building 2, No. 4, 3rd Street, Yinping Road, Shatou Street, Panyu District, Guangzhou, 510030

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and

operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

ISED Canada Statement:

This device contains licence-exempt trasnsmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development

Canada 's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment

RF Exposure Statement

To maintain compliance with IC's RF Exposure guidelincs, This cquipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

Déclaration du Canada:

Ce dispositif contient des transmetteurs/récepteurs trasnsmitters exemptés de licence qui sont conformes à l'innovation, à la Science et au développement économique

Les flux RSS du Canada exempts de licences. L'exploitation est soumise aux deux conditions suivantes:

- 1) cet appareil ne doit pas causer d'interférences et
- 2) ce dispositif doit accepter toute interférence, y compris toute interférence pouvant entraîner un fonctionnement indésirable du dispositif.

Exposition au rayonnement: cet équipement est conforme aux limites d'exposition au rayonnement établies par le Canada pour un environnement non contrôlé
noncé d'exposition RF

Pour maintenir le respect des guides d'exposition RF d'IC, cquipment doit être installé et actionné avec une distance minimale de 20cm leradiateur de votre corps. Cet appareil et ses antennes ne doivent pas être co-localisé ou en opération en conjonction avec toute autre antenne ou émetteur