

Description of the remote control function

Model: 2A9WC-BT002

1. To operate the fan, install 2 AAA batteries in the handheld remote control transmitter
2. If not used for a long time, remove the battery to prevent damage to the transmitter. Store the remote control away from the high temperature and humidity.

	Fan off
	Light on/off (light memory after 10 seconds) CCT switch (fast click to switch)
1-6	Fan speed
	Fan on/off
	Natural wind
	Forward or reverse rotation
	Safe mode(anti-theft mode)
	Delayed off Fan and light will turn off after 5 minutes.
	Remote controller mute
1H 4H 8H	Fan stop after 1 hour Fan stop after 4 hours Fan stop after 8 hours



Remote Controller Pairing:

The remote controller can be used to control multiple ceiling fans.

1. For the ceiling fans you want to pair, turn the main power switch off for at least 1 minute.
2. Turn on the main power switch, then press and hold the  button within 10 seconds.
3. Wait for the fan receiver to make a beeping sound, then release the button.

If the pairing process is unsuccessful, please repeat the above steps.

The wireless transmission frequency is: 433.92MHz

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

