

Video Intercom Camera

Quick start guide

Quick configuration

Step 1 Download APP

Tips one: Scan QR code.



Tips two: Search "ICSee" in the App store or Google play to download.

Step 2 Power on


Powered on camera, it will make a voice "system starting up, wait be configured" after several seconds, you can make the camera pair network. If the camera does not make the voice for long time, please long-press the camera reset button to restore factory settings.

Note:
If you need local storage, please install the TF card firstly, then power on the device (the TF card does not support hot swapping, please plug and unplug the TF card when the camera is powered off). Cloud storage is recommended, which is safe and convenient. Details See "Step 4" for operation.

Step 3 Configure the network of the camera

1. Connect your phone to Wi-Fi network and turn on Bluetooth.
2. Open the ICSee app, register an account and login(Figure 1).

Figure 1



Step 4 Cloud Storage

3. After successful login, click the "+" button (Figure 2).
4. Wait for the device to be added to be found, and click "OK" (Figure 3).

Figure 2





Figure 3



Step 5 Enter the Wi-Fi password and click "OK"

5. Enter the Wi-Fi password and click "OK" (Figure 4).
6. Wait for the camera network configuration, when the camera issues a "connect successfully" voice prompt, indicating that the network configuration is successful(Figure 5).

Figure 4




Figure 5



Step 6 After the network configuration is successful, set the camera name

6. After the configuration is completed, the device is displayed in Smart Device(s). Click to open the real-time preview screen, and do some settings as you want(Figure 7).

Figure 6






Figure 7



Step 7 After the network configuration is successful, set the camera name

7. After the network configuration is successful, set the camera name(Figure 8).
8. After the configuration is completed, the device is displayed in Smart Device(s). Click to open the real-time preview screen, and do some settings as you want(Figure 9).

Figure 8



Function Introduction Video call

Initiate a video call on the mobile phone:

Click the "Video Call" button (Figure 9) on the real-time preview interface to initiate a two-way video call (Figure 10).

Figure 9






Figure 10



Initiate a video call on the camera:

1. Press the left button on the camera side to initiate a video call request.
2. After the mobile phone is answered, it can be two-way video call (Figure 11).

Figure 11



Common Questions

Q: How to save camera recordings?

- A: 1. Local TF card storage, maximum to 128G, when TF card is full, auto delete older videos, keep record video.
2. Recommend cloud storage, Alarm video storage to cloud server, real-time push alarm small video, safe and reliable, you can learn more on APP cloud service page.

Q: How to do if the camera is not connected or offline?

- A: 1. Check if the camera power or network of router normally.
2. Plug the camera power to restart camera.
3. Restore the camera to factory settings.

Notice

1. Please modify the device password right now when the products are turned on.
2. Do not install the device in a place that is damp, dusty, or accessible to children.
3. Please use and store within the allowable temperature and humidity range, and do not disassemble the equipment at will.

Special explanation

1. It is subject to actual products. Quick start guide is just for reference.
2. APP and device firmware will be updated irregularly. Please update online as needed.
3. If there is any inaccurate item or function explanation mistake or typographical error, please refer to our company explanation.

Warranty Card

Product name	Model
Purchase date	Dealer
Issues	
Issues fixing Explanation	
Customer name	Gender
Contact mobile	Post code
Contact address	

Warranty period: One year; this warranty card is applicable to the series of products you purchased from our company.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.