




MA131 user manual

ACCESSORIES:

- Type-C Charging Cable x 1
- User Manual x 1
- Short Stick x 1
- Long Stick x 3
- Plastic Connectors x 2



Speaker control panel



— button:

Press to previous track

Press and hold to decrease volume



Press and hold to power ON/OFF speaker

Press to play and pause track



button: change between 3 LED modes and turn on/off LED lights.

(No need to power ON the speaker, you could turn the candlelight on directly by press this button.)



Press to next track

Press and hold to increase volume

DC 5V : Charging port

BT mode:

1. Power the speaker ON. A tone will be heard and the speaker will enter Bluetooth pairing mode, The LED indicator will quickly flash BLUE.
2. Set your mobile device to search for Bluetooth devices. When the list appears, select **MA131** from the found devices.
3. After a successful pairing, a tone will be heard, and the LED indicator will turn solid BLUE, and you can begin playing music on the speaker.

LED modes

- No need to power on speaker, the light can be turn on by pressing button.

Press button to switch between LED modes or turn LED ON/OFF. There are 3 LED modes:

1. regular speed candlelight;
2. quick speed candlelight;
3. warm candlelight

LED indicator

- Turn red during charging and turn off after being fully charged.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.