

WIRELESS AIR SPRING REMOTE

*Requires Air Springs & Air Spring Controls (sold separately)

Giving you the ability to adjust your air spring pressure from the palm of your hand with the touch of a button. It's the perfect means to control your vehicle's air suspension system from inside or outside your vehicle!

Thank you and congratulations on the purchase of a Wireless Air Spring Remote.

IMPORTANT

For safe and proper operation of the vehicle, never exceed a maximum of 100PSI in the air springs. Staying under the pressure limit will ensure maximum air spring life. Failure in doing so may result in damage to your vehicle and/or a void warrantv.

Safety Warnings!



HELPFUL INSTALL TIP

Additional information that could potentially make the iob a little easier.



PLEASE USE CAUTION

Unsafe practices could result in damage to you, your vehicle, or others.

- Please read and abide the instructions found in this manual, paying close attention to the helpful and cautionary warning icons highlighting important safety recommendations and maintenance suggestions throughout this manual.
- Do not use the device while driving or otherwise operating a motor vehicle.
- Serious personal injury or death may result from an air spring failure or accident due to improper air spring pressure operation or maintenance.

Inflating an unsecured air spring is dangerous. If it bursts, it could be hurled into the air with explosive force resulting in serious personal injury or death. Never inflate an air spring unless it is secured to the vehicle.

ADDITIONAL WARNINGS AND PRECAUTIONS

- Prevent the charging port from coming into contact with foreign materials such as metal, liquids, or dust
 - Do not expose the device to impact, bending, or other physical damage
 - Do not disassemble, crush, or puncture the device
- Do not turn on, use, or plug in the device if the battery pack is exposed, damaged or leaking
- Do not use device in a hot environment or near open flame
- If any part of the device smokes, or emits a burning odour, stop using the device immediately

THIS DEVICE MAY BE DAMAGED IF WATER OR DUST ENTERS THE DEVICE

- Do not immerse the device in water or keep it submerged for extended duration
- If the device is exposed to water, dry it thoroughly with a clean, soft cloth. If the device is exposed to oil, grease, chemicals, or other liquids, carefully rinse it with clean, fresh water and dry it thoroughly with a clean, soft cloth

Failure to follow these instructions may affect the device's performance and/or appearance

DISPOSAL

- This device contains a Lithium-Ion battery. For safe disposal options, contact your nearest service centre
- Be sure to dispose of your device properly. In some areas, the disposal of batteries in household or business trash may be prohibited

WIRELESS REMOTE — LEGEND



Α	Power ON / Power OFF Button		
В	Charging Port [USB Type-C]		
C	Bluetooth	D	Settings / Help
Е	Air Spring Selection: Combined / Separate		
F	Pressure Control	G	Pressure Indicator
Н	Preset Buttons	-1	Battery

WIRELESS REMOTE — USER MANUAL

POWERING THE DEVICE



Power ON — Press and hold the power button (on the right side of the device).

Power OFF — Press and hold the power button, then choose 'Shut Down' in the pop-up menu.

Restart Device — Press and hold the power button, then choose '**Restart**' in the pop-up menu.

B CHARGING DEVICE

The device can be charged by connecting via the **USB Type-C** port to a certified charging head.

The device can be used while charging.

The device may heat up when charging. This is normal and will not affect the life or performance of the device

CONNECTING THE DEVICE

Once the device is powered ON, press the **Connect Device** button.

REMOTE FUNCTIONALITY

BLUETOOTH TOGGLE

Tap the **Bluetooth** toggle to manually connect or disconnect from the controller.

The remote automatically connects to the most recent paired device if it is active and in range on start-up

D SETTINGS MENU

UNITS — Pressure read out can be changed from either PSI or KPA.

CHANNEL MODE — Select between Single or Dual Channel Air Spring Controls depending on the kit the remote is being used with.

Single Channel Mode must be selected when using a <u>single channel kit</u>, since there will be unexpected behaviours if dual-channel mode is used with single channel hardware

CALIBRATE — to recalibrate the pressure sensors, ensure the air springs are fully drained and then press Calibrate.

SCREEN BRIGHTNESS — use the slider to adjust the brightness of the remote's screen.

AIR SPRING SELECTION

Use the Air Spring Selection tab/button to select which air spring(s) to inflate/deflate.

- Combined inflates/deflates both springs simultaneously
- →← Separate inflates/deflates each air spring independently

AIR SPRING PRESSURE CONTROL

Press and hold the Inflation (\$\inft) or Deflation (\$\inft) button to adjust the pressure in the air springs.

 PLEASE NOTE: The wireless remote does not limit the minimum or maximum pressure in your air springs.

Inflate your air springs according to your air spring manufacturer's guidelines.

G PRESSURE INDICATOR

The **Pressure Indicator** shows the pressure of each air spring with an accuracy of $\pm 5\%$ over the entire range.

The presets allow for rapid adjustment to the desired pressure (\pm 1 PSI).

PRESET BUTTONS

Use the Preset Buttons to save your pressure presets.

To save a current air spring pressure as a preset, press and hold one of the 3 preset buttons.

The preset button will display the currently saved pressure value(s).

 A message will appear on the bottom of the screen indicating the preset has been saved successfully

Use these presets anytime to quickly adjust to the desired pressure.

WIRELESS REMOTE DISCLAIMERS

DISCLAIMER

Driving while distracted can result in loss of vehicle control that may lead to an accident, severe personal injury, or death.

The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any hand-held devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation

NOTE 2: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC NOTICE

This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le pré sent appareil est conforme aux CNR d' Innovation, Sciences et Dé veloppement é conomique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisé e aux deux conditions suivantes:

- (1) l'appareil nedoit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioé lectrique subi, mê me si le brouillage est susceptible d' en compromettre le fonctionnement.

Operation of 5150-5250 MHz is restricted to indoor use only. Le fonctionnement de 5150-5250 MHz est limité à une utilisation en inté rieur uniquement.

Radiation Exposure Statement:

The device has been tested and comply with FCC/ISED SAR limits.

L'appareil a é té testé et est conforme aux limites SAR de la FCC/ISED.

WIRELESS REMOTE WARRANTY

WARRANTY

Complete warranty details are available online by visiting:

Pacbrake.com/mm5/pdfs/L5753.pdf

Or by scanning the QR code here:



Must be completed online for eligibility:

Pacbrake.com/warrantv



