

磁吸车载无线充支架 Instruction manual

Magnetic car wireless charging bracket

使用说明书 User Manual



型号 Model: A666-B

产品介绍 Product Introduction

感谢您购买本公司产品，本产品是一款车载磁吸无线充电器手机支架。

本产尺寸小巧，外观简洁，支持单路最大 15W 输出，输入电压突变检测，过流检测，线圈峰值限制，过热限制，以保证接收手机在安全工作范围。

Thank you for purchasing our product, this product is a car magnetic wireless charger mobile phone holder. This product is small in size and simple in appearance, and supports a single channel with a maximum output of 15W, input voltage mutation detection, overcurrent detection, coil peak limit, and overtemperature limit to ensure that the receiving mobile phone is within a safe working range.

内置环形磁铁，强稳吸力，手机靠近产品附近自动磁吸对准无线充电区域，随放随充，横竖多角度使用模式，360 度旋转，自由视角，行车导航更安全 使用本产品前请认真阅读本说明书并妥善保存，以备查阅。

Built-in ring magnet, strong and stable suction, the mobile phone is automatically magnetically aligned with the wireless charging area near the product, charging at any time, horizontal and vertical multi-angle use mode, 360°-degree rotation, free viewing angle, safer driving navigation. Please read this manual carefully before using this product and keep it properly for future reference

产品明细图（以系列支架其中 7#支架为例说明）

Product detail diagram (Take the series of brackets, among which the 7# bracket is an example)



1,金属主体 metal body 2,固定公头胶配件 Fix the male glue fittings 3,Type_c 接口 Type_c socket 4,固定旋钮螺母 Fix the knob nut 5,紧固旋钮 fastening knob 6,出风口叶片挂勾 Air outlet blade hook 7,系列固定支架 1# ~ 16# 为车载出风口夹装配方式 (17#,18#,19#,20#:为吸压式固定) Series of fixing brackets 1#~16# is the assembly method of the car air outlet clamp (17#, 18#, 19#, 20#: it is fixed by suction pressure)


使用说明(以出风口夹装式) Instructions for use (with air outlet clamp-on)

1# ~ 16#为车载出风口夹装配方式固定 , 17#,18#,19#,20#:为吸压式固定

1#~16# is fixed for the assembly method of the vehicle air outlet clamp,

17#, 18#, 19#, 20#: it is fixed by suction pressure

- 1, 将支架旋转球套上充电器螺帽; Rotate the bracket ball over the charger nut;
nut;



- 2, 将支架旋转球按压进充电器固定圆孔, 并旋紧充电器螺帽(箭头处螺帽);

Press the bracket rotating ball into the charger fixing round hole, and tighten the charger nut (nut at the arrow);



- 3, 将支架插入空调出风口, 勾好并旋转支架螺帽, 固定充电器;

Insert the bracket into the air outlet of the air conditioner, hook and rotate the bracket nut to fix this wireless charger;



4，调整好角度，将 Type_C 数据线插入，指示灯亮起;

Adjust the angle, insert the Type_C data cable, and the indicator light will be on;



产品参数 Product parameters

型号 Model: A666-B
输入 Input: 5V/2A , 9V/2A (Max)
输出功率 Output power: 5W /7.5W /10W /15W (Max)
接收距离 Receive distance: < 5mm
接口类型 Interface type: Type_C

注意事项 Precautions

- 1: 请放置儿童接触不到的地方; Keep out of reach of children
- 2: 不能在潮湿环境下使用; Do not use in a humid environment;
- 3: 禁止私自拆卸产品; It is forbidden to disassemble the product without permission;
- 4: 请避免强烈摔打,碰撞此产品; Avoid strong blows and collisions with this product;
- 5: 非专业人员,请勿自行打开,维修此产品; Non-professionals, do not open and repair this product by yourself;
- 6: 特别注意本产品需要配备 QC/PD2.0 , QC/PD3.0 等正规过认证车载充电器来适配; Please use QC/PD2.0, QC/PD3.0 and other formal certified car chargers to power this wireless charger;
- 7: 手机背面不能带有指环扣, 增加手机厚度物品或金属物件有以上物体将影响手机无线充的使用和充电功率。The back of the mobile phone cannot have a ring clasp, and the thickness of the mobile phone or metal objects will affect the use and charging power of the wireless charger.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.