

60mm


110mm

# JOYIDEAVA


## JY-26

### BLUETOOTH SPEAKER

#### 【Instruction Manual】




#### 1: Top button (Microphone function)



- ① Short press to switch modes.
- ② Long press to decrease volume; Short press to the previous song.
- ③ Short press to pause play in Bluetooth/TF/USB/AUX play mode; Short press in AUX play mode to mute play.
- ④ Long press to increase volume; Short press to the next song.
- ⑤ Turn on the microphones, the speaker will automatically connect to the microphones. Long press to connect/disconnect the microphones, short press to switch the microphone sound effects modes.
- ⑥ Long press to enable clock adjustment, short press to switch hour/minute adjustment, then short press "Volume+/Volume-" to adjust the time value. After adjustment, the adjustment mode will be automatically closed.
- ⑦ Short press to switch the light effects in cycle; Long press to turn on/off light.


#### 2: Top button (No microphone function)



- ① Short press to switch modes.
- ② Long press to decrease volume; Short press to switch to the previous song.
- ③ Short press to pause play in Bluetooth/TF/USB/AUX play mode; Short press in AUX play mode to mute play.
- ④ Long press to increase volume; Short press: next song.
- ⑤ Long press TWS button to pair other JY-26 speaker, long press TWS button to disconnect.
- ⑥ Long press to enable clock adjustment, short press to switch hour/minute adjustment, then short press "Volume+/Volume-" to adjust the time value. After adjustment, the adjustment mode will be automatically closed.
- ⑦ Short press to switch the light effects in cycle; Long press to turn on/off light.

1

#### 3: Back interface



- ① Pull left, Power on; Pull right, Power Off
- ② Type-c Power interface
- ③ 3.5mm Audio input jack
- ④ Maximum support U Disc 128G
- ⑤ Maximum support 128G

#### 4: Technical parameter

- Product model : JY-26
- Bluetooth version : V5.0
- Bluetooth distance : ≥10M
- Speaker power : 40W
- Battery capacity : 10800mAh
- Working hours : ≈4 Hour (100% Volume)
- Talk time : ≈20 Hour
- Full charge time : ≈5 Hour
- Charge mode : Type-C 5V/3A
- Product size : L250xH130xW130MM

(All technical information is subject to actual performance)


#### 5: Bluetooth connection



2

#### 6: TWS Series connection

( Only support the model without microphone )



#### 7: Display definition

1. When turned on, the display screen will show the play mode, which will change back to time display after 30 seconds without any operation.
2. When playing in Bluetooth, TF card, USB flash drive, and AUX modes, the display screen will show the corresponding mode and slowly flash. If the play is paused, it will display normally.

#### Warranty statement

##### Disclaimer

This manual is without any warranty, position expression or other implication, the products, specifications and information mentioned in this manual are for reference only, and the content will be updated from time to time on the website without prior notice.

##### Warranty statement

Make the following warranties for the Products attached to this document: If the products are damaged due to quality defects under normal use within twelve (12) months from the date of purchase (the "Warranty Period"), they will be repaired free of charge; Can not be repaired by the manufacturer, free replacement; After repair or replacement of the product, in the remaining warranty period (minimum of not less than 30 days) continue to enjoy the warranty. The date of purchase is subject to the date of the sales invoice; If the date of purchase cannot be determined, the warranty period shall be calculated for thirteen (13) months from the date of manufacture of the product. To apply for warranty, please call the product service hotline first and follow our instructions.

When applying for warranty, you need to provide a valid sales invoice that is accurate, complete and clearly filled out.

The above warranty does not apply to:  
1. More than three packages of validity;

3

#### Warranty statement

2. Because the warranty card and product code are inconsistent with the product body;
  3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
  4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
  5. Off-line or tear caused by excessive load;
  6. Any damage caused by sharp objects;
  7. Products with signs of burning or flooding;
  8. Damage caused by unauthorized demolition;
  9. Aging, decolorization, wear, breakage and other losses that occur during the normal use of the product;
  - 10 If the original identification label of the product is changed or damaged, this warranty will be invalid;
- The completeness and appearance of the product and accompanying materials are not guaranteed and you should inspect the product on the spot and object to any discrepancy upon receipt of the product.

The above warranties are all warranties made by us with respect to our products and are only applicable in Mainland China. Of this document Nothing in the content affects consumer rights that cannot be excluded or limited by law.

##### FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
Recent or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement.  
The device has been evaluated to meet general RF exposure requirement.  
The device can be used in portable exposure condition without restriction.

4