


User's Manual




TYD-ZLQ-001




Attention

- ◆ The intensity of the light projector is high, so please don't look at the light source directly.
- ◆ This light source is not replaceable, when the light source reaches the end of life, the entire lamp should be replaced.



Host Key Operation Instructions




Attention: The product needs to be connected to the power cord to use.

- ◆ **Main Switch:** Short press the Main Switch to turn on the equipment, the default after power on projection lamp and ambient lamp. Long press the button again after turning on to turn off.
- ◆ **Projection Light Switch:** Each time you press the button, the projection switches a color, After a cycle, it returns to the default color. Long press to turn off the projection. Short press to reopen the projection lamp after turning off.
- ◆ **Ambient Lamp Switch:** Power on the default on ambient lamp, long press to turn off the ambient lamp function
- ◆ **Timing Indicator:** When you press the remote control timing button, the Indicator light up and turn off the Indicator off.
- ◆ **Bluetooth Indicator:** When Bluetooth is turned on, the Indicator is on (the previous Indicator is blinking when not paired, the Indicator is always on after successful pairing), and the Indicator is off when Bluetooth is turned off.

How do I connect to a product via Bluetooth?

Turn on the Bluetooth feature. When the Bluetooth Indicator blinks. The Bluetooth feature is turned on and ready to connect to your phone. The Bluetooth is named "Lander Projection Lam". Turn on your phone Bluetooth and search, when "Lander Projection Lam" appears, select this option to pair. When the pairing succeeds, there is a prompt for a successful connection and the Bluetooth Indicator changes from blinking to always on.

Remote Control Instructions



- ◆ **Main Switch:** Short press the switch to turn on the equipment, the Projection Lamp and Ambient Lamp are turned on by default after turning on; Short press the button again after turning on to turn off.
- ◆ **Timing Switch:** Press the Timing Switch to enter 45 minutes of timing, at the same time give a hint "DI," the Timing Indicator lights blue, short press can be switched to 90 minutes of timing, while issuing twice hint "DI," the Timing Indicator lights red. Long press the Timing Switch to turn off the timing function.
- ◆ **Projection Lamp Brightness +:** Projection Lamp brightness for a total of 5 gear, the default brightness is intermediate, each time press the button, brightness added one gear.
- ◆ **Projection Light Switch:** Each time you press the button, the projection switches a color, After a cycle, it returns to the default color. Long press to turn off the projection. Short press to reopen the projection lamp after turning off.
- ◆ **Projection Change Speed -:** Projection change speed is 0-1-2-3-4 five gears, 0 gears for static. fourth gears is the fastest, the default gear is second gears, each time press the button, the Projection change speed is reduced one gear, the lowest to 0 gears.
- ◆ **Projection Change Speed +:** Each time press the button the projection change speed increases by one gear.
- ◆ **Projection Lamp Brightness -:** Projection brightness of a total of 5, the default brightness is intermediate, each time press the button, the brightness reduced by one gear.
- ◆ **Ambient Lamp Switch:** Ambient Lamp turning on by default after turning on the equipment, long press the button to turn off the ambient lamp function.

Material: ABS/PC/PVC/Silica gel
Rated Voltage: 5V±2A
Control Mode: Remote control
Remote Control Range: <5meters(Best distance)
Product Size: 147*115*115mm
Applicable Environment: Indoor (Better in a dark environment)
Working Temperature: 10°~40°Celsius



Do not look directly at the laser light source!
This is not a toy, children should not use it alone, please use it with an adult!



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.