

Bluetooth headset PF-N18

Function description:

- Play/Pause: Click the function key once/the earphone Hall function can control play/pause
- Incoming call answering: function key click once
- Call rejection: Press and hold the function key for 2 seconds
- Call back: After the hang up operation, the function key will call back for 2 seconds
 - Press the previous song '-' twice in a row
 - Press the "+" button twice in a row for the next song
 - Volume increase: "+" keeps pressing and increasing
 - Volume decrease: "-" Keep pressing and keeping decreasing
- Indicator light prompt description: The red and blue lights alternately flash on/off, and the red light flashes 3 times
- Connection prompt: green light flashes once every 5 seconds
- Press the Siri function key three consecutive times to access the Siri function
- Low battery alarm: When the battery is below 10%, the red light flashes once every 2 seconds and prompts once every minute
- Charging display: The charging status blue light is on, and the fully charged to blue light is on for a long time

- FCC STATEMENT
- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the
 - following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that
 - may cause undesired operation.
 - 2. Changes or modifications not expressly approved by the party responsible for
 - compliance could void the user's authority to operate the equipment.
 -
- NOTE: This equipment has been tested and found to comply with the limits for a
 - Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed
 - to provide reasonable protection against harmful interference in a residential
 - installation.
- This equipment generates uses and can radiate radio frequency energy and, if not
 - installed and used in accordance with the instructions, may cause harmful
 - interference to radio communications. However, there is no guarantee that
 - interference will not occur in a particular installation. If this equipment does cause
 - harmful interference to radio or television reception, which can be determined by
 - turning the equipment off and on, the user is encouraged to try to correct the
 - interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which
 - the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
 -
- RF warning statement:
 - The device has been evaluated to meet general RF exposure requirement.
 - The device
 - can be used in portable exposure condition without restriction.
-