AS-SP187 User Manual

Technical Specifications:

Bluetooth version	AB5.3
Model No	AS-SP187
Bluetooth transmission	≥10m
Battery Capacity	3.7V 1200mAh
Output power	8W
Horn spec	4Ω52mm
Frequency response	120Hz-18Khz
Sensitivity	85db
Power supply	5V/1A
Products size(L*W*H)	123x93x53mm
Weight	341g

Features and operation

1. ⏻ button: Long press to power on/off the speaker. Short press the button to switch different mode(Bluetooth/ FM/ USB/ Micro SD card) . When you turn on two speaker, double click the power button any of speaker, you can pair the TWS mode.

2. **+** button: Short press to increase the volume, long press to next track.

3. **▬** button: Short press to decrease the volume, long press to previous track.

4. ▷ button: Short press to play/pause the track. Hold and press this button to reject the call, short press to answer/hang up. Double click to redial the last call.

LED charging indicator:

1. Bluetooth pairing status: Blue indicator flashing.
2. Pairing successful: Blue light flashes during playback.
3. Charging status: red indicator stay solid.
4. Charging finished: red Indicator off.

Bluetooth Operation:

1.Turn on the speaker, it will make a tone and ready to pair.
2.In the list of your device, select and pair with "AS-SP187" . After successfully connected, the speaker will prompt a tone. The blue indicator will stop flashing and stay solid.

Note: ①If necessary, please enter password "0000" and click OK.
② The speaker will memorize and automatically connect the last paired device in next time.

TWS connection operation

To action TWS mode, both speakers need to be in pairing mode and disconnected from any device.

Press and hold the ⏻ button on either speaker to enter TWS mode. A short audio prompt is heard. Once paired, you can then pair to your device.

Under TWS condition, disconnect the BT device and long press the ⏻ button, you can unpair from TWS mode.

When unpairing, a short tone sound is heard to indicate TWS is cleared and the speaker will return to normal BT pairing mode.

TF card play:

Insert a TF card, you will hear a prompt tone. It can decode and play MP3 format audio.

USB disk play:

  Insert a USB, you will have a prompt sound. It can decode and play MP3 format audio.

Low battery:

When the speaker is in low battery, you will hear a prompt sound. Please charge it, otherwise, it will be power off automatically.

FCC Statement：

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.