


K118




PRODUCT INSTRUCTIONS


PRODUCT PARAMETER.

Brand:	exs uly
Bluetooth version :	BT5.4
Bluetooth name :	K118
Support protocol :	HFP V1.7;HSP V1.2;A2DP V1.3;AVRCP V1.6
Charging current :	Earbuds:DC5V—5mA, Charging case :DC5V—1A
Charging time:	Earbuds:1hours , Charging case: 2 hours
Music time :	About 8.5 hours
Transmit distance :	≤15 m (Barrier free)
Capacity :	Earbuds:50mAh,Charging case:400mAh
Frequency resopnse range:	20HZ--20KHZ

PRODUCT LIST.



PRODUCT ILLUSTRATION.



1. Left earphone
2. Right earphone
3. Power display screen
4. Charging case
5. Touch area of left earphone
6. Touch area of right earphone


INDICATOR LIGHT INSTRUCTIONS.

1. Place the charging box into the left and right earphones, and the digital display running light flashes to charge the earphones;
2. When Type-C is charged with a cable, the digital display font on the screen flashes, and when fully charged, the digital display font remains on.

(Please be sure to use 5V/1A charging cable or attached charging cable when you purchasing products)


FOR FIRST USE.

1. Bluetooth name: K118 ;
2. Instructions for use: After opening the packaging, remove the headphones from the charging compartment;
3. Pairing connection: Open the lid, take out the left and right earphones and place them on the desktop or hand. Wait for 3-5 seconds, and the two earphones will automatically pair. Then search for the Bluetooth name on the phone: K118, and click on the Bluetooth name to connect;
4. Power on: Open the cover, pick up the automatic power on, pair and connect the previous device;
5. Shutdown: Replace the charging compartment, close the cover, and automatically shut down for charging;




1. Open the charging case of the headset, take out the headset and enter the Bluetooth pairing state.

2. Open the Bluetooth setting function of the mobile phone, select "K118" and confirm that the pairing is successful.



WEARING INSTRUCTIONS.

- 1 Confirm the left and right earphones.
L - left ear, R - right ear.



- 2 Rotate the ear hook to the maximum angle.




- 3 Rotate the ear hook of the earphone backward along the auricle until it is in the appropriate position.



- 4 Wearing is completed.



ILLUSTRATION OF TOUCH AREA.



OPERATION INSTRUCTIONS.


1. Bluetooth name: K118 ;
2. Instructions for use: After opening the packaging, remove the headphones from the charging compartment;
3. Pairing connection: Open the lid, take out the left and right earphones and place them on the desktop or hand. Wait for 3-5 seconds, and the two earphones will automatically pair. Then search for the Bluetooth name on the phone: K118, and click on the Bluetooth name to connect;
4. Power on: Open the cover, pick up the automatic power on, pair and connect the previous device;
5. Shutdown: Replace the charging compartment, close the cover, and automatically shut down for charging;
6. Left ear long touch volume decreases;
7. Long touch volume increase in the right ear;
8. Touch the left/right ear twice to call Siri;
9. Touch the next song three times with the right ear;
10. Touch the previous song three times in the left ear;
11. Click on the left/right ear to pause playback;
12. Click on the left/right ear to answer the call and hang up the call;

MATTERS NEEDING ATTENTION

1. Please reasonably control the volume and time of using the headset to avoid hearing damage;
2. Do not use headphones in potentially dangerous environments to ensure safety;
3. Try to avoid using headphones to listen to music, make or receive phone calls while driving, so as not to distract attention and cause danger;
4. Please place earphones out of reach of children to avoid danger caused by improper use of children;
5. Avoid storing or using headphones at temperatures lower than -20 C or higher than 45C, which will shorten the life of the headphones and battery;
6. Do not disassemble, repair and transform this product by yourself;
7. The battery of this product is not replaceable. Please dispose of it according to local regulations or recycle it by a professional organization. Do not discard it at will
Throw into the fire;
8. When the headset is not used for a long time, please charge the headset every 3 months to extend the battery life of the headset;
9. Do not expose the battery to high temperature environments such as sunshine and fire;
10. The output voltage and current of the charger are not greater than 5V/1A, if the output voltage and current of the charger exceed the limit value, it is possible Will cause serious damage to the product, product warranty will be void at the same time;

11. Please dispose of waste electronic products correctly, and do not discard electronic and electrical equipment, components, batteries and other household garbage together;
12. Please charge in a safe environment. When charging the charging bin, please pull out the charging cable as soon as possible after the charge is full to avoid long Time charging causes damage to the battery.

**Thank you for purchasing this product.
Wish you a pleasant use!**



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.