

REMOTE CONTROL AND CAR OPERATION

① Press the left horizontal button, the tank moves to the left.



② Press the right horizontal button, the tank moves to the right.



③ Press the turn left button, the tank turns to the left.




④ Press the turn right button, the tank turns to the right.



2.4G AUTO PAIRING INSTRUCTIONS

1. Install the batteries in the back of the remote control. Turn the remote control on, the indicator light will flash. Turn on the RC tank. The tank and remote control will pair automatically. If there is any issue, turn everything off, make sure all the batteries are new/charged and then turn the remote and tank on again.
2. Each remote control can only be linked to one tank. When the connection is successful, each tank will not interfere with each other.
3. If pairing is not successful, it will enter sleep mode after 45 seconds. While playing with the tank, if there is no operation or 5 minutes the tank will enter sleep mode to preserve battery.

REMOTE CONTROL FUNCTION DESCRIPTION




- 2 -

CHARGING

1. Charge the 3.7v battery before use.
2. Insert the battery's wire plug into the charger's plug paying attention to the correct polarity. Plug the USB end into a USB port for charging.
3. Charging takes 2-3 hours. The light on the charger will be red when charging and will turn off when fully charged.

WARNING: Do not leave the battery on the charger once the battery is fully charged. Do not charge unattended. It is recommended to keep the battery in a Li-Po safe bag (not included) and do not expose the battery to direct sunlight or heat.



HOW TO INSTALL THE BATTERY

1. Remote control.
 - a. Open the battery cover of the remote control and install the AA batteries (not included) according to the polarity of the positive and negative poles in the battery compartment of the remote control.
 - b. Close the battery cover and replace the screws.
2. Remote control tank.
 - a. Open the battery cover under the tank, connect the rechargeable battery to the power socket and put it into the battery compartment under the tank.
 - b. Close the battery cover and replace the screws.



- 3 -

Federal Communications Commission (FCC) Statement.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Exkaliber LLC** may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement: This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.