


AIO PC
RPD-1400T



User Manual
RAYPODO GROUP (HK) LIMITED


Important Notices

Copyright Information
Important Notices Copyright Information All intellectual property rights in this publication are owned by and protected by applicable copyright laws and international treaty provisions. RAYPODO retains all rights not expressly granted. No part of this publication may be reproduced in any form whatsoever or used to make any derivative work without prior written approval by RAYPODO.RAYPODO reserves the right to revise this publication, and/or make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time without prior notice. The information in this document is provided in good faith, but without any representation or warranty whatsoever, whether it is accurate, complete, or otherwise, and on the express understanding that RAYPODO shall have no liability whatsoever to other parties in any way arising from or relating to the information or its use.All other trademarks are the property of their respective owners. Other company and brand product and service names are trademarks or registered trademarks of their respective holders.Do not expose this product to moisture or place any objects filled with liquids on or near the product.Do not place a naked flame source, such as lighted candles, on or near this product.Do not store or operate the device in environments where the temperature is above 50 degrees Celsius or below -10 degrees Celsius.Do not intentionally hit the device or place heavy or sharp objects on the device. Only use accessories specified by the manufacturer.Keep the device away from benzene, diluents, and other chemicals.Do not attempt to repair this product yourself. Always use a qualified service agent to perform adjustments or repairs.




Package Contents

Please make sure all of the following are present when you unpack your INTERACTIVE DIGITAL SIGNAGE




INTERACTIVE DIGITAL SIGNAGE



Power adapter



User manual




Wall mounted bracket

Products only are mounted on the Wall using a Wall mounted bracket.

Features

- 14"LCD panel
- 10.1"Resolution(1280*800)/14"resolution1920*1080
- Rockchip RK3568 Quad-core Cortex-A55 up to 2.0GHz
- RAM 2GB (Option 4GB)Internal memory 32GB
- Android 11
- 10-Point capacitive touch
- 2.0M/P,front camera
- Bluetooth 5.0
- WiFi 802.11b/g/n
- RJ45 ethernet with POE
- Micro SD card,support up to 128GB
- Serial port
- USB host
- USB 3.0 host (3568)
- USB OTG
- 3.5mm earphone +micphone
- HDMI output
- 2*3W speaker
- VESA:75x75mm
- Adapter:12V/3A

14"Exterior Components




No	Function	No	Function
1	Camera	7	USB 3.0 host(3568)
2	3.5mm earphone+micphone	8	DC power supply port
3	HDMI output	9	Power button
4	RJ45 ethernet with POE	10	Speaker
5	Micro SD card	11	Speaker
6	USB OTG	12	Kensington lock

Locating Wi-Fi Settings

To access the Wi-Fi settings on your device, follow these steps:
1) Open the Settings Menu:Navigate to the main menu of your device and select the Settings option.
2)Locate the Network or Connectivity Section:In the settings menu, find the section labeled Network, Wireless Connections, or Connectivity.
3)Select Wi-Fi:Under the network settings, tap on Wi-Fi to access the list of available wireless networks.
4)Connect to a Network:Choose your preferred Wi-Fi network from the list, enter the required password if prompted, and confirm to establish the connection.
5)Verify Connection:Once connected, you will see a Wi-Fi icon in the status bar or on the screen, indicating an active connection.



Locating Wi-Fi Settings



Locating Bluetooth Settings

Locating Bluetooth Settings

To access the Bluetooth settings on your device, follow these steps:
1)Open the Settings Menu:Navigate to the main menu of your device and select the Settings option.
2)Find the Bluetooth Section:In the settings menu, look for Bluetooth or Connections. It may also be located under Device Settings.
3)Enable Bluetooth:Tap on Bluetooth to turn it on. A Bluetooth icon may appear in the status bar indicating that it is active.
4)View Available Devices:Once Bluetooth is enabled, the device will scan for nearby Bluetooth-enabled devices. A list of available devices will be displayed.
5)Pair with a Device:Select the device you wish to pair with and follow any on-screen prompts to complete the pairing process.
6)Verify Connection:After pairing, the connected device will appear in the list with a “Connected” status.



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed of at the end of its life separately from your household waste. There are separate collection systems for recycling in your country. For more information, please contact the local authority or your retailer where you purchased the product.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.ct.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.