





Bluetooth Pairing Operation Instruction for OS



- Note:
1. Only one device can be actively paired at one time.
 2. Once the connection between your tablet and the keypad is established, your device will connect to the keypad automatically when you switch on the keypad in future use.
 3. In case of connection failure, delete the pairing record from your device, and try the above pairing procedures again.

1. Turn the power switch to green side, blue indicator will be on, press pair button, the bluetooth keypad will enter pairing condition while the blue indicator keep flashing.

2. Power on the iMac/Macbook and select the setting icon on the screen, click it to enter the system preferences list.



3. Click the Bluetooth icon to enter the iMac bluetooth device searching condition.

4. In the iMac bluetooth device searching list, you can find the "Bluetooth Keypad", click it to connect .

5. After the iMac connect the bluetooth keypad successfully, you can start to use the keypad for typing freely.

6. In connected condition, if the blue indicator keep flashing, please use the charging cable to charge the keypad till the red indicator off.

Bluetooth Pairing Operation Instruction for Windows



1. Turn the power switch to green side, blue indicator will be on, press pair button, the bluetooth keypad will enter pairing condition while the blue indicator keep flashing.

2. Power on the laptop or desktop and start the windows, click the windows icon in the left bottom side, select and click the setting icon in the show up menus.

3. In the setting menu, select and click the devices icon, then select and click the Bluetooth in the devices list, you will enter the bluetooth device menu.


4. Turn on the bluetooth and click the symbol "+" to add new bluetooth device, the laptop or desktop will enter searching condition.

5. In the bluetooth device searching list, you can find the "Bluetooth Keypad", click it to connect .

6. After the laptop or desktop connect the bluetooth keypad successfully, you can start to use the keypad for typing freely.

7. In connected condition, if the blue indicator keep flashing, please use the charging cable to charge the keypad till the red indicator off.

Bluetooth Numeric Keypad
User's Manual



- Note:
1. This keypad is perfect for smartphone, laptop, desktop and tablets, compatible with Windows, Android, iOS and OS operation system;
 2. Please charge the keypad about 2 hours before use;
 3. Please read the user manual carefully before you start using this product

Made in China

Keypad Maintenance

1. Please keep the keypad away from liquid or humid environment, saunas swimming pool, steam room and don't let the keypad get wet in the rain.
2. Please don't exposes the keypad at too high or too low temperature condition.
3. Please don't put keypad under sun for a long time.
4. Please don't put keypad close to the flame, such as cooking stoves, candles or fireplace.
5. Avoid shard objects scratching products, timely to recharge products to ensure the normal use.

FAQ

1. The tablet PC can't connect the BT keypad ?
-Checking the BT keypad battery is enough, the battery low is also lead to can't connect, you need charge.
2. The keypad indication light always flashing when use ?
-Keypad indication always flashing when use, it means the battery is low power, please charge the keypad as soon as possible.
3. The table PC display BT keypad is disconnect?
-The BT keypad will into dormant to save the battery after some time later not use, press any key the BT keypad will beawken and working.

Hotkeys of keypad

This keypad provides hotkeys of the top cover.

: Print Screen

: Search

: Activate the calculator application(only in Windows)

Esc: Same as Esc key function (when the calculator is open, it indicates reset)
Tab: Tabulator key for Windows, to activate the bluetooth keypad in iOS calculator input

Function key features may have variations depending on the operation system version and devices

Technical Specifications

Keypad size : 146*113*12mm	Operation current : <3mA
Weight : 124g	Standby current : <0.5mA
Working distance : ~10m	Sleep current : <10uA
Lithium battery capacity : 110mAh	Sleep time : 20 minutes
Working voltage : 3.0~4.2V	Awaken way : Arbitrarily key to awaken

Status Display LED

Connect : In power on condition, the blue light keep flash when it enter pair status.

Charging : In charging condition, the red indicator light will be on until the battery is fully charged.

Low Voltage Indication : When the voltage is below 3.2V, blue light twinkles.

Remarks : In order to prolong the life span of the battery, when you do not use the the keypad for a long time, please switch off the power.

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this quick start guide without the permission of seller.

Safety instructions

Do not open or repair this device, do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

Warranty Card

User information

Company or personage full name

TEL _____ Zip _____

The purchased product name and model NO.

Purchased date _____

- This reason due to the product broken and damage is not include on the warranty.
- (1) Accident, misuse, improper operation, or any unauthorized repair, modified or removed
 - (2) Improper operation or maintenance, when operation violation of the instructions or connection unsuitability power supply.



71*105mm

105g双铜纸双面单黑印刷

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction