



User manual

Register your product and get support at www.philips.com/support

Table of contents

| | |
|---|----|
| 1. Important Safety Instructions | 2 |
| Hearing Safety | 2 |
| General Information | 2 |
| 2. True Wireless Earphones | 3 |
| What's in the Box | 3 |
| Other Equipment | 3 |
| Overview of True Wireless Earphones | 4 |
| 3. Getting Started | 5 |
| Charging the Battery | 5 |
| Wearing Methods | 6 |
| Pairing the Headphones with a Bluetooth Device for the First Time | 6 |
| Pairing with Another Bluetooth Device | 7 |
| 4. Using the earphones | 8 |
| Connecting to a Bluetooth device | 8 |
| Power on/off | 8 |
| Managing music and calls | 8 |
| Voice assistant | 9 |
| Earphone LED status | 9 |
| 5. Reset the headset | 10 |
| 6. Technical Data | 11 |
| 7. Notices | 12 |
| Declaration of conformity | 12 |
| Disposal of old product and battery | 12 |
| Removal of integrated battery | 12 |
| Compliance with electromagnetic field (EMF) regulations | 13 |
| Environmental information | 13 |
| Declaration of conformity | 13 |
| 8. Trademark | 15 |
| 9. Frequently asked questions | 16 |

1 Important Safety Instructions

Hearing safety



Danger

- To avoid hearing damage, limit the time you use headphones at high volume and set the volume to a safe level. The louder the volume, the shorter the safe listening time.

Please make sure to follow these guidelines when using headphones

Listen at a reasonable volume for a reasonable amount of time

- After your hearing has adapted, be careful not to keep turning up the volume.

Don't turn up the volume so high that you can't hear the sounds around you.

- Use headphones with caution or suspend use in potentially dangerous situations.

Excessive sound pressure from headphones can cause hearing loss.

It is recommended not to wear headphones in both ears while driving. Doing so may be illegal in some areas.

For safety reasons, avoid driving yourself with music or calls while driving or in other potentially dangerous situations.

General Information

To avoid damage or malfunctions

Warn

- Do not expose the headset to high temperatures. Do not leave the headset lying in a scorching surface. (Refer to the rating on the specific product.) Do not immerse the headset in water. Do not damage the headset when the headset is not in use. Do not use any cleaning agent containing alcohol, acetone, benzene or thinner to clean the product.
- If necessary, clean the product with a cloth only, which can be wet with a small amount of water or diluted neutral soap and water. Do not use alcohol or other solvents.
- There is a risk of explosion if the battery is not correctly inserted. Recharge the battery in a safe place. Recharge the battery only with facilities of the supplier.
- To enhance a specific function, the charging plug must be inserted. Recharge the battery in a safe place. Recharge the battery only with facilities of the supplier.
- Recharge the battery in a safe place. Recharge the battery only with facilities of the supplier.
- There is a risk of explosion if the battery is not correctly inserted. Recharge the battery in a safe place. Recharge the battery only with facilities of the supplier.
- To avoid the risk, the device can only be powered on in a safe place. Recharge the battery in a safe place. Recharge the battery only with facilities of the supplier.

Operating and storage temperature and humidity

Store the product in an environment with a temperature between -20°C (-4°F) and 60°C (140°F) and a relative humidity of up to 95%.

Operate the product in an environment with a temperature between 0°C (32°F) and 40°C (104°F) and a relative humidity of up to 95%.

High humidity or rain can damage the product. Do not use the product in a high humidity or rain environment.

Recharge the battery with an original type or a compatible device. Do not use the product in a high humidity or rain environment.

2 Open Wireless Sports Headphones

Welcome to buy and use Philips products! To ensure that you fully enjoy the support provided by Philips, please visit www.philips.com/support to register your product. With this Philips true wireless headset, you can:

- Enjoy convenient wireless hands-free calls
- Enjoy convenient music wirelessly
- Switch between calls and music

What's in the box



Philips open wireless sports headphones Philips TAA1708




Type-C charging cable (for charging only)

Other Equipment

A Bluetooth-enabled phone or device (e.g. laptop, tablet, Bluetooth adapter, MP3 player, etc.) that is compatible with the headset.

Overview of Open Wireless Sports Headphones



- ① Microphone
- ② LED indicator
- ③ Multi-function button (MFT)
- ④ Volume + button
- ⑤ USB-C charging port

4 CN

3 Getting Started

Battery Charging

Notice

- Before using the headset, connect the headset to the USB-C charging cable and charge the battery for 2 hours. This will ensure optimal battery power and life.
- Only use the original USB-C charging cable to avoid any damage.
- Charge after ending the call. The headset will automatically turn off when the battery is fully charged.
- If the headset is not used for a long time, the rechargeable battery will lose its capacity. To avoid this loss, fully charge the battery at least once every three months.

USB-C charging cable

Connect one end of the USB-C charging cable to the charging port of the headset and the other end to a power source.



How to wear

Insert the earphones

- Check the left and right orientation of the earbuds.
- Insert the earphones into your ears and twist gently until they fit secure.




6 CN

耳机

将耳机连接 USB-C 充电线。

- 耳机开始充电，蓝色 LED 指示灯亮起。
- 当耳机充满电时，指示灯熄灭。



Hint

Normally, make sure to fully charge the headset on a USB cable.

5 CN

Pairing the headset with a Bluetooth device for the first time

- Make sure the headset is fully charged and powered off.
- Press and hold the multi-function key for 4 seconds.
- The LED indicator on the headset flashes white and blue alternately.
- The headset is now in pairing mode and can be paired with a Bluetooth device (such as a mobile phone).
- Turn on the Bluetooth function of the Bluetooth device.
- Pair the headset with the Bluetooth device. Please refer to the user manual of the Bluetooth device.

Note

After powering on, if the headset cannot find any previously connected Bluetooth device, set it to pairing mode (after 1 minute, if the headset has not been connected, it will automatically enter pairing mode).

The following example shows how to pair the headset with a Bluetooth device.

- Turn on the Bluetooth function of the Bluetooth device and select Philips TAA1708.
- If prompted to enter the headset password, enter "0000" (4 zeros). For Bluetooth devices with Bluetooth 2.0 or higher, no password is required.



Philips TAA1708

Pairing with another Bluetooth device

If you want to pair another Bluetooth device with the headphones, first press and hold the volume button on both headphones for 4 seconds to enter pairing mode, and then pair with the second device (as usual).



Note

The headset memory can store 4 devices. If you try to pair more than 4 devices, the oldest paired device will be automatically deleted.

7 CN

4 Using headphones

Connecting to a Bluetooth device

- Turn on the Bluetooth function of the Bluetooth device.
- Press and hold the multi-function button for 4 seconds.
- The blue LED indicator flashes.
- The headset will search for the last connected Bluetooth device and automatically connect to it. If the last connected device is not available, the headset will search and connect to the second last connected device.

注意

- 耳机开始充电，蓝色 LED 指示灯亮起。
- 当耳机充满电时，指示灯熄灭。

注意

在充电过程中，耳机可能会自动充电。在此情况下，您必须按照设备的充电说明。请勿将耳机连接到蓝牙耳机。

8 CN

Voice Assistant

| Trigger | Multi-function key | Operation |
|--------------------------------------|---------------------|-----------|
| Toggle Voice Assistant (Siri/Google) | Short press 3 times | |
| Stop Voice Assistant | Single click | |

Power on/off

| Task | Multi-function key | Operation |
|---------------------|------------------------------|-----------|
| Turn on headphones | Press and hold for 4 seconds | |
| Turn off headphones | Press and hold for 2 seconds | |

Manage music and calls

| Task | Multi-function key | Operation |
|---------------------|--------------------|-----------------------------------|
| Play or Pause Music | Short press | |
| Next Song | Volume + key | Long press and hold for 2 seconds |
| Previous Song | Volume - key | Long press and hold for 2 seconds |
| Adjust Volume + | Volume + key | Short press |
| Adjust Volume - | Volume - key | Short press |

Call control

| Task | Multi-function key | Operation |
|------------------|---------------------|-----------|
| Answer the call | Short press | |
| Hang up the call | Short press | |
| Reject the call | Short press 2 times | |

Headphone LED status

| Headphone status | Indicator lights |
|--|--|
| Headphones connected to Bluetooth | White LED flashes once every 5 seconds |
| Headphones ready to pair | Blue and white LED flash alternately |
| Headphones turned on but not connected to a Bluetooth device | White LED flashes once per second (auto-off after 2 minutes) |
| Low battery (headphones) | Blue LED flashes 2 times every 5 seconds |
| Battery low | Blue LED on |
| Battery relatively high | White LED on |
| Not charging | Indicator lights |
| Battery low | Blue LED flashes slowly for 4 cycles |
| Battery relatively high | OFF |

9 CN

5 Reset the headset

If you encounter any pairing or connection issues, you can follow the steps below to reset the headset to factory settings.

- Select the Bluetooth menu of your Bluetooth device and delete Philips TAA1708 from the device list.
- Turn off the Bluetooth function of your Bluetooth device.
- Make sure the headset is not connected to a Bluetooth device.
- Press and hold the Volume + button/Volume - button for 4 seconds to clear all information.
- Follow the steps in "Using the headset - Connecting the headset to a Bluetooth device".
- Pair the headset with your Bluetooth device and select Philips TAA1708.

10 CN

6 Technical Data

- Music playback time: 8 hours
- Charging time: 2 H
- Both earphones are equipped with 140mAh lithium-ion batteries
- Bluetooth version: V5.3
- Compatible Bluetooth profiles: HFP (Hands-free Profile) A2DP (Audio and Video Remote Control Profile) AVRCP (Audio and Video Remote Control Profile)
- Supported audio decoding: SBC
- Frequency range: 2.402-2.480GHz
- Transmitter power: <10 dBm
- Effective distance: <10 M
- Automatic power off
- USB-C charging port
- Low battery warning: Provided

Note

Specifications are subject to change without notice.

Removing the integrated battery

If your country does not have a collection/recycling system for electronic products, protect the environment by removing and recycling the battery before disposing of the headset.

- Before removing the battery, make sure the earphones are disconnected from the USB-C charging cable.



However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference, you may be required to relocate the equipment or use shielding to reduce the interference. Shielding is not possible at all.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 2cm between the radiator and your body.

Warning: Any changes or modifications to the product not expressly approved by the party responsible for the compliance with the regulations could void the user's authority to operate the equipment.

Canada

This device contains a "license-exempt transmitter" as defined by the Canadian Radio-television and Telecommunications Commission (CRTC). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

12 CN

Compliance with Electromagnetic Field (EMF) Regulations

This product complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Environmental information

All necessary efforts have been made to ensure that the packaging used to transport these products is made from plastic (excluding) and polystyrene (excluding) and is 100% recyclable.

Please observe local regulations for the disposal of packaging materials, used batteries and end equipment.

Compliance Statement

This device complies with Part 68 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device must not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Regulations

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 68 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

12 CN

IC Radiation Exposure Statement

This device complies with Canadian radio-interference exposure limits set forth for an uncontrolled environment.

This transmitter must not be used in an uncontrolled environment. Its use is limited to mobile use only. It is not to be used in a fixed location. It is not to be used in a fixed location. It is not to be used in a fixed location.

14 CN

8 Trademark

Bluetooth

The Bluetooth word mark and logo are registered trademarks of Bluetooth SIG, Inc. and any use of such marks by HMD Hong Kong Holding Limited is under license. Other trademarks and trade names are trademarks and trade names of their respective owners.

Siri

Siri is a registered trademark of Apple Inc. in the U.S. and other countries.

Google

Google and Google Play are registered trademarks of Google LLC.



15 CN