


ENGLISH




Intelligent visual doorbell

Please read the instructions before use

ENGLISH


Product Introduction



ENGLISH

Indicator Flashing Rules:

1. When the doorbell is pressed, the blue light stays on for two seconds and then turns off.
2. PIR induction: Blue light repeatedly flashes on and off.
3. Charging: solid red.




4. Fully charged: The blue light is always on, and it will turn off after unplugging.

ENGLISH

Doorbell & Chime Pairing

1. Plug the Chime into power outlet.
2. Press and hold the 2 keys(volume key and music key on the Chime)holding them, then press and hold the doorbell button until hearing the prompt from the Chime.
3. Done.



ENGLISH

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference with residential installations. This equipment generates, uses and can radiate radio frequency energy and, if not properly installed and used, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If interference does occur, you may wish to take one or more of the following measures, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and another.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ENGLISH

Download com720 APP from APP store or Google play, or by Scanning the QR code below.




Tips:APP is free (if the APP store prompt binding the credit card, pls click ignore at below) (if the grey button)

ENGLISH

Sign up & Login

1. Click "Register" to enter your Email address
2. Get the verification code from the Email and enter it
3. Set the password for your APP account and remember it.
4. Done



Tips:Recommend using hotmail@gmail.com, International general Email.


ENGLISH

Wi-Fi connection

Find the RESET button, press and hold the reset button for 5 seconds to reset the camera until you hear "B+", continue to wait for "Di+" 2 times, and the camera will complete the self-test.

NOTE:

1. Only support 2.4GHz WiFi, pls choose 2.4G WiFi to connect.
2. Gate doorbell to reset the router.
3. Cellphones and doorbell connected to the same WiFi.
4. Don't tap the APP permission avoid to can't find the doorbell successfully.




Help: the distance of signal at a distance of two meters

The device connects to the router via WiFi.


ENGLISH

1. In the APP: Click "+" and select "WiFi Connection".
2. Tick "Hear Device Prompt Di+", Click Next.




ENGLISH

5. Follow the prompts shown in the app (please connect the WiFi to the "jk-****" and return to the Cam720 app).



ENGLISH

4. Enter the correct password for your phone's WiFi connection and click "Next".
5. After the device is connected, please wait patiently until the camera Camera is online.



ENGLISH

4. After connection successfully, pls follow the APP guide to enter "test step" until the device list, please follow the guide APP to enter the "test step" until the device list.



ENGLISH

Explanation of the function

1. Add more camera.
2. Modify the device name.
3. Start Live video.
4. Subscribe Cloud storage.
5. More functions setup.
6. View > Information.
7. Return to the device list.
8. Power Information.
9. Show the device.
10. More function settings.
11. Change Resolution(CAM).
12. Enter Full screen mode.
13. Speaker Button.
14. Take a screenshot to save the picture.
15. Recording screen.
16. View the playback.
17. Quick voice reply.
18. Select the working mode.



ENGLISH

Explanation of the function

1. Ringtone settings & Forced diversion alarm.
2. Alarm information push & Sound alarm.
3. Working mode & Battery power.
4. Switching Camera Networks.
5. Camera MAC & ID & Security Setting.



Note: The device needs to be in "Live Preview Mode" to make settings.

ENGLISH

Working Mode & Set



Note: Change live monitoring mode to other modes freely, but change other working modes to "Live monitoring mode", it needs camera work by pressing the ball button.

ENGLISH

Playback

Select the date and open the desired time mode, where you can filter the desired event recordings.



ENGLISH

Doorbell installation and removal

Base mounting

Install the Mounting Base vertically on the flat brick wall outside the door in the direction indicated by the arrow. Try to avoid mounting on metal materials.



H = 1.2-1.4m

ENGLISH

Doorbell installation

Align the doorbell mounting notch with the base fling slot, and push it horizontally, then slide down about 5mm until you hear a "click" sound to finish install.



Doorbell disassembly

Please turning off the forced disassembly alarm in the APP at first. Then insert the disassembly pin into the disassembly hole above the doorbell camera. At the same time, please slide the doorbell up about 5mm and take it out in parallel.



ENGLISH

How to use the doorbell properly

1. Please make sure that the doorbell is within the Wi-Fi signal coverage range, and select the best location for the signal.
2. Try to avoid installing on metal materials and partition wall (solid areas) to avoid signal interference.
3. Avoid direct sunlight to avoid signal interference.
4. When not in use for a long time, fully charge it at least once every 3 months.
5. This product does not support 5GHz Wi-Fi network.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation

ENGLISH

FAQ

Q1:Failed to do WiFi connection?

A1:Check the prompt of the APP,if you have tried 2 times, message seller or market@qccy.com with the prompt screenshot and order number to get the assistance.

Q2: Doorbell is often offline?

A2: (1) Check the Power of the doorbell and WiFi signal range. (2) If it's signal issues,pls check the distance away from the router and the install place material is the right. (3) delete the device,reset the doorbell and re-connect it again as the first time done before. (4) Message seller or market@qccy.com to get the assistance.

Q3: Can't set up?

A3: Pls check the working mode,if it's not"live monitoring mode",it needs press the doorbell to let the camera work,then change the working mode to "live monitoring mode" in the APP.

After-sale Service & Tech Support

Need some help?

E-mail: technical@qccy.com market@qccy.com

for user guides, FAQs, warranty & more.

Scan the QR code below to enter Youtube to view the video demonstration.



Check and learn about WiFi connection video