



100.0 mm




对折位



60x100mm, 70g 书纸, 单黑, 双面印刷, 对折

产品功能介绍：

M18



使用方法：

1. 打开鼠标电源开关，长按底部蓝牙按键3S以上，底部对应通道的指示灯会进入快闪，鼠标可在120S内与设备进行配对；
2. 打开设备蓝牙进行搜索，连接成功后，对应通道指示灯常亮3S后熄灭
3. 最多支持蓝牙三通道连接 (通道1 BT3.0/通道2 BT5.2/通道3 BT5.2)




指示灯说明：

1. 支持3档DPI: 800/1200/1600, 顶部指示灯红灯闪烁一次为800, 红灯闪烁2次为1200, 红灯闪烁3次为1600
2. 低电提醒：顶部指示灯红光闪烁60S



2

Overview:**M18****Instruction:**

- 1.Turn on the mouse.Keep pressing the Bluetooth button at least 3 seconds to pair.The mouse is discoverable for 2 minutes.
- 2.Complete Bluetooth pairing on your device. When the mouse and your device are paired, the light turns off.
- 3.Supports up to three Bluetooth connections (Channel 1 BT3.0/ Channel 2 BT5.2/ Channel 3 BT5.2)

**Status LED:**

1. Support 3 DPI:800/1200/1600.The top red status led blinks once for 800, twice for 1200 and three times for 1600.
- 2.Low battery:The top red status led blinks for 60 seconds.

2

- 1
- 2
- 3

Any changes or modifications not expressly approved by the party responsible for compliance could void the user ' s authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.