

# Remote Control Operation Instructions

## 1. Matching

When the remote control and the driver are paired for the first time, you need to perform code operation. First, long press the "SET" key for 2 seconds to enter the code alignment state, hold down the "SET" key at this time do not let go, and then power on the drive to complete the code alignment. The above steps are operated once again to clear the code, so the cycle.



## 2. Reset Mode

When the lifting leg is stopped, long press the "RST" key of the remote control for 3 seconds, and the drive will emit a long buzz, indicating that it automatically enters the reset state. The lifting leg will automatically drop to the lowest level and bounce back the base height. The drive will emit two long buzzes, indicating that the reset is complete.

## 3. Height setting

Press the button of the remote control "△"、"▽" can adjust the height of lifting leg; Press the "HOME" button to automatically return the lifting leg to the lowest position, and press it again to stop the operation.

## 4. Recall Memory

Long press the "M1" key or "M2" key of the remote control for 3 seconds, and the drive will emit a long buzzer, indicating that the current location memory is successful; Press the "M1" or "M2" key, and the lifting leg will automatically run to the memory position.

## **5.FCC Statement:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

Equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.