

QUICK START GUIDE

Wireless IP Camera

Thank you for using Rxview Pro. Please setup the camera by following the steps

1. In order to connect the camera stably, please install it in the range that could

Before installing the camera, please determine the installation

When the camera is installed in a place where is difficult to obtain Wi-Fi signal.

Please keep the wires away from children to avoid any

In order to get the best image quality, please don't touch the





1. Download the APP

 Download the "Rxview Pro" app from the App Store(IOS devices) or Good Application pre-check function Play (Android devices).





strongly accept the Wi-Fi signal of the home wireless router.

location(flat surface or wall)

please use a Wi-Fi extender to extend the Wi-Fi network range.



camera lens with your hands.

Please make sure to use the matching power adapter cable. or the camera may not work properly.







Scan the OR code below to download the APP





2. Connect the power connector to the camera and plug the power adapter into a power outlet. Wait until the camera status LED turns solid red.

3. Create an account and tap "Add Device" to add a device into your device list, follow the instructions to complete the setup.

Recommended system specifications

Wi-Fi 802.11 b/g/n IOS 11.0 or higher Android OS 6.0 or higher

Make full use of Rxview Pro to monitor your home(the supported functions

Event notification

Choose Region

Forgot Password?

Don't have a account? Sign Up

may be varied by different models):

Motion/Human/Vehicle/Package/Sound detection Customized real-time monitoring

Voice intercom


accept the relevant privacy

Lagree to the Terms of Service Use and Privacy Policy

policy,then tap <Sign Up>.


Run Rxview Pro.then tar Input user's information then tap

Return to the login <Get Verification Code>, Verification interface, input user name code will be sent to your email. and password,Choose Input the verification code, read and Region, then tap <Login>.



After tap <Login> will reach the Home

.ııl 🗢 🖿



Plug the adapter into an outlet. Wait until the camera indicator

10:59 4

1. First, power on the device.

Blue steady or blue slow flashing.

Red and blue alternating flashing.


Other indicator light statuses.

Red slow flashing.

on.Tap button<Add Device> in the right corner of the main menu. Aim the scanning window at the QR code on the camera. ← Scan QR Code



Tap button <Red slow flashing when the camera LED is blinking




Tap button <Next> to connect camera Select a 2.4GHz/ 5GHz WIFI

network for the camera to connect

and input the WIFI password, tap

Wi-Fi Configuration

button <Next>.



<Next>to connect WIFI.

Please setup a Login password for your device.

User name

New password

Confirm new password

Password rules


Input the password, Tap button Waiting for the WIFI connecting.


Wi-Fi connecting, please wait

Device was added successfully and tap <Next>.

or customize a device name vou

Set a device name, you can choose














where you want to setup your

America_Anchorage America_Araguaina America_Arizona America_Atka America_Chicago America_Denver

Please insert micro SD card and tap <Next> to format Micro SD. If you forgot to insert Micro SD, you can insert Micro SD and tap <Check


No microSD card detected.

card.



Tap <Format> to format micro SD

Tap <Got it> after formatting successfully.



Select a desired way to mount the camera according to the installation Guide.

On Desk

Ceiling Mounted

configuration.


Tap <Finish> to finish camera



Mount bullet camera onto a wall



Place cube camera on a table




(4) Mounting the Camera

②Drill and install anchors

Anchors are not required

if the wall is made of wood

Keep a gap of more than 10 inches (25cm) between objects to the side of Rotate the camera to adjust the view angle and check it by using the live the camera lens to avoid overexposure caused by infrared light reflection stream which you can access in the SmartCam View app.




Screw the mounting bracket


O Press the camera to

until click into place


Keep a gap of more than 10 inches (25cm) between objects to the side of the camera lens to avoid overexposure caused by infrared light reflection.



Mount the PT camera on celling



Place cube camera on a table



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

Unplug the camera power connector from the power adapter.

• Find a spot where the camera can easily reach a power outlet. Make sure the camera receives a strong Wi-Fi connection in the

spot where you want to mount it so that it can stream video to

(2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and canradiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined bturning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- -Reorient or relocate the receiving antenna.

Before mounting the camera:

your SmartCam view app.

- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
- This equipment should be installed and operated with minimum distance 20cm between the radiator & your body







Keep a gap of more than 10 inches (25cm) between objects to the side of

② Drill and install anchors

Screw hole

Anchors are not required

if the wall is made of wood



