

90.00 mm



## Wireless Headphones



### SDL-718

Instruction manual

55.00 mm

55.00 mm

55.00 mm

55.00 mm

55.00 mm

### Important instruction

In order to be responsible for your hearing, It is recommended that use the earphones according to your situation, choose the appropriate decibel level and the appropriate volume to avoid hearing damage.

Sound	Noise level(dB)	Effect
bass	30	very quiet
quiet office	50-60	comfortable hearing lever are under 60 db
vacuum cleaner / hair drye	70	interferes with telephone conversations
food blender	85-90	staying this situation 8 hrs will damage hearing
garbage truck / cement mixer	100	no more than 15 minutes of unprotected exposure
power saw / jackhammer	110	you will have the risk of hearing damage when exposure to sound over 100db frequency more than 1 minute.
Rock Concerts	110-140	ears will be painful immediate, no matter how long you stay in this situation.

### Let ears enjoy music comfortably

1. Please obey the suggestions of audiologist. Don't turn up your Player volume too high, don't wear earphones for a long time, please keep your ear have a rest properly.
2. If you hear the sound is too piercing, please low down the volume or stop using.
3. Please be sure to correctly wear the right or left earphones which make you a good feeling to enjoy perfect and comfortable music. "L" for left ear, "R" for right ear.

Model:SDL-718  
Wireless version:V5.4  
Working frequency: 2402-2480MHz  
Transmission distance: ≥ 10 meters  
Best working distance: <6meters  
Drive unit: Ø40mm  
Impedance:32Ω ± 15%  
Sensitivity:121dB ± 3dB

Frequency response: 20Hz – 20kHz  
Battery capacity:  
:Lithium battery 3.7V / 300mAh  
Music time: About 30 hours(LED turn off)  
Call time: About 25 hours  
Standby time: About 90 hours  
Input voltage: Type-C / DC5V / 1000mA  
Charging time: About 1.5 hours

① Long press for 3 seconds: turn on/off;  
② Pause/play/answer calls/hang up;  
Music mode: short press the power button: play/pause  
Incoming call/call status: short press the power button to answer or hang up;  
③ Music Mode:  
Double-tap the power button --- next song  
Triple-tap the power button --- previous song  
④ Bluetooth connection status:  
Press the power button 5 times in succession---Disconnect the current Bluetooth connection

⑤ 1.Double-click the M button --- EQ switch (game mode/music mode)  
2.Triple-click the M button --- (F1) pairing on/off  
⑥ Volume +/- - Rotary volume switch



### Operation

1. Please fully charge the headphones for the first time. Please plug the Type-c-usb cable into the charging port and connect it to the power supply. It takes 2-3 hours to fully charge.(based on battery capacity)
2. When the headphones battery is exhausted, an alarm will be heard, please charge it immediately. If you use the headphones after warning, the headphones will power off automatically after 1.5 minutes.

### Power on / off

- 1.Power on: press and hold the "Power on/off" button for 3 seconds and release it. The indicator light will turn blue and red. Ready to connect.
- 2.Power off: hold down the "Power on/off" button for 3 seconds and then release it. The indicator light is off and power off.

### Wireless use

Wireless mode provides hands-free functions and wireless music player functions

1. When holding down the switch button for 3 seconds to power on the headphones, the indicator light flashes alternately blue and red, and voice prompts enter wireless pairing mode. Turn on the wireless function on the phone, search for device name SDL-718 and select it to connect. After a successful connection, you can play music and make a call.
2. When the device is successfully connected to the headset, the indicator light will go out.

### Charging:

1. Connect the charging cable to the charger and insert it into the TYPE-C port of the headset. The headset starts charging.
2. The red LED light is always on when charging, and the blue LED light is always on when fully charged.

### FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.**

### Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.