







RIICHI-STYLE-HD (board)

NO.1

Product name	①Dice box rise sensor board (The dice box moves up and down, allowing tiles to be dropped into the table)	②-1 Elevator sensor board (Position sensor to return the elevator to its upper limit) 4 locations.	③Extrusion sensor board (return to home position sensor) 4 locations	④Count sensor board (Detects tiles and counts them. Pushes them out to the EL and returns them to their original position) hand tiles sensor: 4 locations Building tiles sensor: 4 locations Dora turner sensor: 4 locations	⑤Dice base (Roll the dice, start the game, etc.)	⑥Control board (game selection)	⑦Main board Software name : JP3_MANCON Created on: August 3, 2024
	JT30 VER.2.05	SF01 VER:3.30	JT30 VER:1.03	SENS-001 REV.1	YB430 VER:1.02	KEY-5 VER:1.03	LG807 VER:1.10
Main substrate front and back photograph							
Frame board front and back photos		