



VIMOTO Motorcycle Communication System

VIMOTO WILD BTR Quick Guide



(WILD BTR)



(WILD V10X/V10S)





Bluetooth



Product Overview



Mainboard Button



Indicator Light



Charging Port  
(Type-C)



Volume Up Button



Multi Function Button



Volume Down Button



Bluetooth Intercom Button



Important Note:  
Before using headphones, please pair morboard and Remote first. When performing subsequent operations, ensure that morboard and remote remain connected to guarantee normal functionality.

Indicator Light



Pairing In Progress



Red & Blue Lights Alternating



Charging



Red Light Solid



Charging Complete



Red Light Off



Multi-Riders Intercom (Private Mode)  
Group Remote In Progress



Intercom Light Fast Blink



Bluetooth Multi-Riders / Dual-Riders  
Intercom Intercom In Progress



Intercom Light Slow Blink



Pairing In Progress



Red & Blue Lights Alternating



Disconnected



Blue Light Slow Blink  
(Low Battery, Red Light Slow Blink)



Intelligent Voice Active



Blue Light Fast Blink  
(Low Battery, Red Light Fast Blink)



Connected  
(Phone/DODO/Adapter)




Blue Light Double Blink  
(Low Battery, Red Light Double Blink)



In Call/DODO Intercom



Blue Light Triple Blink  
(Low Battery, Red Light Triple Blink)



Awaiting Reconnection



Blue Light Fast Blink  
(Low Battery, Red Light Fast Blink)

Power On/Off & Factory Reset



Power On/Off



Long Press(3s)



(Power-Off State)  
Power On



(Power-On State)  
Power Off



Blue Light Illuminates  
For 1s n Turns Off



Power On Prompt Tone



Red Light Illuminates  
For 1s n Turns Off



Power Off Prompt Tone



Factory Reset (Ensure Mainboard & Remote Connected)



Simultaneous Button Press(3s)



Red And Blue Lights Solid For 2s



"Factory Reset Complete"

Note: Device Will Automatically Power Off After A Successful Factory Reset.

Pairing Of Mainboard And Remote



Mainboard Start Pairing (Power-Off State)



Long Press(6s) To Star Pairing  
(Mainboard)

Note: Auto Cancel Pairing After 120s.



Remote Start/Cancel Pairing



Press And Hold Both Buttons For 3s To Star/Cancel Pairing  
( Remote )



Pairing Of Mainboard&Remote



Long Press(6s) To Star Pairing  
(Mainboard)



Long Press(3s) To Pair  
(Remote )

Quick Pairing (Before Pairing, Ensure Mainboard & Remote Are Connected)



Pair With Phone



Long Press(3s) To Pair  
( Remote )



Bluetooth Search & Pair  
(Phone)



Pair With DODO

Note: Pair With DODO After Phone Pairing.



Long Press(3s) To Pair  
( Remote )



Bluetooth Search & Pair  
(DODO)



Cancel Pairing



Long Press(3s) To Cancel Pairing  
(Remote )

Reconnect



Auto-Reconnect Power On



Long Press(3s)

Note: Auto-Reconnect To Phone/Adapter On Power-On.



Manual Reconnect 1



Short Press  
(Mainboard)



Awaiting Reconnection  
(Phone)



Manual Reconnect 2



(Remote)

Note: After Morboard Is Turned On, When Remote Control Board Is Paired Without Connection, Press Any Key To Connect Back.

Battery Level Audio Announcement



Auto Power On Alert



Auto Low Battery Alert



Long Press(3s)

Note:Power On Auto- Battery Report.



(Battery <15%, Announces Every 10 Mins)



"Low Battery, Please Charge"



Manual Battery Alert



Long Press(1s)  
(Idle)

Or



Long Press(1s)  
(Idle)



Low Battery Auto-Off



(Battery <5%, Auto-Shutdown in 10s)



"Low Battery, Shutting Down Soon"

Call



Answer Call



End Call



Activate Voice Assistant



Deactivate Voice Assistant



Voice Command: [Xiao Wei, Xiao Wei]



(Incoming Call)  
Short Press



(Call In Progress)  
Short Press



(No Call/DODO Intercom)  
Double Press



(Voice Assistant Active)  
Double Press



Reject Call



Cancel Call



Unmute Microphone



Mute Microphone



(Incoming Call)  
Long Press(1s)



(Outgoing Call)  
Short Press



(Microphone Muted)  
Long Press(1s)



(Call In Progress)  
Long Press(1s)



"Microphone On"



"Microphone Muted"



Enable Auto Answer



Disable Auto Answer



(With Auto Answer Disabled)  
Simultaneous Button Press(1s)  
"Auto Answer Enabled"



(With Auto Answer Enabled)  
Simultaneous Button Press(1s)  
"Auto Answer Disabled"



Increase Call Volume



Decrease Call Volume



(Call In Progress)  
Short Press



(Call In Progress)  
Short Press

Music



Play Music



Pause Music



(When Music Is Paused)  
Short Press



(When Music Is Playing)  
Short Press



Previous Track



Next Track



(When Music Is Playing)  
Long Press(1s)



(When Music Is Playing)  
Long Press(1s)



Increase Music Volume



Decrease Music Volume



(When Music Is Playing)  
Short Press



(When Music Is Playing)  
Short Press

Background Music Playback



DODO Intercom & Music Mixed



Listen To Music While Using DODO Intercom



Bluetooth Multi-Riders Intercom & Music Mixed



Listen To Music Bluetooth Multi-Riders Intercom



Bluetooth Dual-Riders Intercom & Music Mixed



Listen To Music Bluetooth Dual-Riders Intercom

DODO Intercom



Increase Intercom Volume



(DODO Intercom In Progress)  
Short Press



Decrease Intercom Volume



(DODO Intercom In Progress)  
Short Press

Bluetooth Multi-Riders Intercom



Public Mode



Intercom Light Slow Blink



"Multi-Riders Intercom Public Mode"  
(Auto-Connect, Announces "X People"  
When Number Changes)

When Public Mode Is Enabled, Device Will Automatically Connect To Riders Within Discoverable Bluetooth Range.  
(Up To 8 Riders)





Create An Intercom Group



Long Press(3s)

(Riders Who Need To Join/Create An Intercom Group)



Intercom Light Fast Blink

"Multi-Riders Intercom Group Started"



Auto-Connect

"Intercom Group Members: X"



Any Member:  
Short Press To Save Network

Confirm That All Riders Are Fully Connected Based On Audible Prompt



Intercom Light Slow Blink

"Intercom Group Created Successfully"



Cancel Intercom Group



Group Remote In Progress



Long Press(3s)

"Cancel Multi-Riders Intercom Group Remote"



Unmute Microphone



Mute Microphone



(Microphone Muted)  
Long Press(1s)



(Multi-Riders Intercom)  
Long Press(1s)



"Microphone On"



"Microphone Muted"



Increase Intercom Volume



Decrease Intercom Volume



(No Music In Multi-Riders Intercom)  
Short Press



(No Music In Multi-Riders Intercom)  
Short Press

Bluetooth Dual-Riders Intercom



Pairing: Compatible With V10x/V10s/XR/V9X/V9S/V8S

(Both Headset 1 And Headset 2 Must Perform The Step)



Long Press(3s)

Red & Blue Lights Alternating

"Please Pair"



Short Press

Red & Blue Lights Alternating

Intercom Light Fast Blink

"Dual-Riders Intercom Pairing"



Automatic Pairing

Dual-Rider Intercom ParingSuccessful



Blue Light Slow Blink

Intercom Light Slow Blink

Dual-Rider Intercom ParingSuccessful,  
Intercom Headset Connected"



Cancel Pairing



Long Press(3s)

(During Dual-Riders Intercom Pairing)

"Cancel Pairing" "Cancel Dual-Person Intercom Pairing"




Unmute Microphone



Mute Microphone



(Microphone Muted)  
Long Press(1s)



"Microphone On"



Increase Intercom Volume



Short Press

(No Music During Dual-Person Intercom)



Decrease Intercom Volume



Short Press

(No Music During Dual-Person Intercom)

Intercom Mode Switching



Multi-Riders Intercom Private Mode



Dual-Riders Intercom



Multi-Riders Intercom Public Mode



Intercom Off



Short Press



DODO Intercom



Multi-Riders /  
Dual-riders Intercom



Double Press

Note:  
1. DODO Intercom: RDODO Intercom Can Only Be Switched To When Device Is In Foreground With Screen Active.  
2. Switch Back To Last Used Intercom Mode (Multi-Riders Or Dual-Riders).

#### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

#### FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.