

说明书


材质：普通书纸

印刷：黑白双面

85.00 mm

120.00 mm

issues that need attention



If you have not used this device for more than a month, charge it before using!

Troubleshooting

No electricity

If your speaker device has a power switching switch, please move this switch back to "ON", or connect the charging cable to charge the speaker for a while.

No Sound

Turn on the speaker.

Increase the volume of your speaker, mobile device, and music source.

Move our mobile device closer to the speaker and away from any interference or obstructions.

Poor sound quality

Use a different music source.

Pair another mobile device.

Move our mobile device closer to the speaker and away from any interference or obstructions.

Portable Bluetooth speaker | Model:S10



Product User Manual

Panel functions



- ▶ When playing music: Press to pause / play the music;
- Press and hold to switch function modes; Double Press for TwS pairing (in Mold Only)ByPhone Calls: Press to Answer/End a Call:Press and Hold to DeclineIncoming Cal:Double Press to Call Back (in Mold Only)
- Press to previous song
- Press and hold to reduce the volume.
- Press for the next song;
- + Press and hold to increase the volume
- ✖ Press to change the light mode
- Press and hold to control the ON and OFF light

External Jack Functions

ON/OFF

Power switch.

DC 5V

External DC power supply 5V.

USB/TF

Support to play music file stored on USB disk / TF Card

Loading instructions

Connect the charging cable to charge the speaker, the charging indicator lights up at the same time.

Turn off the speaker while charging,

Wait up to 4 hours to fully charge the battery

Use 1200mA charging current to protect the battery.

Connect the charging cable to connect the display if the built-in battery is damaged.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction