

Product operation instructions

1 Power supply specification

Use AAA1.5V * 2 alkaline battery to load the remote controller in polarity

2 LED explain

The remote control interface includes 44 buttons and one indicator light

- 1) During the Bluetooth connection, press the key LED on and turn off after release.
- 2) When Bluetooth is not connected, press the key LED and flash for 2 times.

3 Pair

press "OK" + "VOL-" LED for 3 seconds and release the button to enter pairing mode; LED is off; LED is automatically withdrawn after 30 seconds, device name: vSeeBox [] Remoter

4 Voice

Press the Voice " to start the voice function

5 Dormancy mode and wake-up

- A. The remote control enters dormant within 10 seconds without any operation
- B. In hibernation mode, support to press any key to wake up.

6 Low power indicating function

When the supply voltage is less than $2.3V \pm 0.05V$, pressing the button LED flicker 10 indicates that the battery quantity is low and the battery needs to be replaced in time.

7 Learn the instructions

How to program  /  /  / 

1. Press and hold  for 5 seconds.
The LED goes from blinking to solid and STB RCU enters learning mode.
2. Press the key to be programmed on this RCU. LED begins blinking slowly. The key is ready to accept programming.
3. Aim the TV RCU towards the front of this RCU (distance less than 3cm). Press the button on the TV RCU. If the STB RCU is programmed correctly, the LED will flash 3 times.
4. Repeat steps 2-3 for other keys.
5. Exit learning mode by pressing any other button on this RCU. LED turns off.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction