










SWC182T 3.1说明书 (带安装说明)

size:625x155mm

材质: 128G双铜, 双面单色印刷

<p>Warranty Clause</p> <p>1. Within half a month from the date of sale, in case of performance failure, the goods themselves and outer packaging must be kept intact (without scratches), and the same type of goods can be replaced (subject to inspection), but not including man-made damage. 2. The warranty service is valid only under normal use. 3. All types of damage such as man-made damage, self-dismantling, unpacking and improper use are not covered by the warranty. Note: When your warranty card is torn or lost, you have lost the warranty opportunity, and our company has the final right to interpret the information.</p> <table border="1" data-bbox="380 830 1060 1000"> <tr><td>Date of purchase:</td><td>Maintenance time</td><td>User feedback problem</td><td>Maintenance verification problem</td><td>Attn</td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> </table>	Date of purchase:	Maintenance time	User feedback problem	Maintenance verification problem	Attn											<p>Warranty Card</p> <p>Product model: _____ Date of purchase: _____ User name: _____ Contact number: _____</p> <table border="1" data-bbox="1250 702 2065 1043"> <tr><td>Product model</td><td>_____</td></tr> <tr><td>Customer name</td><td>_____</td></tr> <tr><td>Contact number</td><td>_____</td></tr> <tr><td>Contact address</td><td>_____</td></tr> <tr><td>Date of purchase</td><td>_____</td></tr> <tr><td>Maintenance date</td><td>_____</td></tr> <tr><td>User feedback problem</td><td>_____</td></tr> <tr><td>Maintenance verification problem</td><td>_____</td></tr> <tr><td>Attn</td><td>_____</td></tr> </table> <p>* Please pay attention to keep the warranty with the card</p> <p>Name and Content of Toxic Substances or Elements in Products</p> <table border="1" data-bbox="1223 1149 2038 1469"> <thead> <tr> <th rowspan="2">Name</th> <th colspan="6">Toxic and harmful substances or elements</th> </tr> <tr> <th>Lead (Pb)</th> <th>Mercury (Hg)</th> <th>Cadmium (Cd)</th> <th>Hexavalent chromium (Cr6+)</th> <th>Polybrominated biphenyl (PBB)</th> <th>Polybrominated diphenyl ether (PBDE)</th> </tr> </thead> <tbody> <tr> <td>Host</td> <td>x</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> <tr> <td>Accessories</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> </tbody> </table> <p>○ It means that the content of the toxic substances and harmful substances in all homogeneous materials of this part is below the limit requirements specified in SJ/T11363-2006 standard. × It means that the content of the toxic and harmful substances in at least one homogeneous material of the part exceeds the limit requirement specified in SJ/T11363-2006 standard.</p>	Product model	_____	Customer name	_____	Contact number	_____	Contact address	_____	Date of purchase	_____	Maintenance date	_____	User feedback problem	_____	Maintenance verification problem	_____	Attn	_____	Name	Toxic and harmful substances or elements						Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr6+)	Polybrominated biphenyl (PBB)	Polybrominated diphenyl ether (PBDE)	Host	x	○	○	○	○	○	Accessories	○	○	○	○	○	○	 <p>Product Qualified Card Date: _____ QC: _____</p>		 <p>USER MANUAL</p>
Date of purchase:	Maintenance time	User feedback problem	Maintenance verification problem	Attn																																																												
Product model	_____																																																															
Customer name	_____																																																															
Contact number	_____																																																															
Contact address	_____																																																															
Date of purchase	_____																																																															
Maintenance date	_____																																																															
User feedback problem	_____																																																															
Maintenance verification problem	_____																																																															
Attn	_____																																																															
Name	Toxic and harmful substances or elements																																																															
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr6+)	Polybrominated biphenyl (PBB)	Polybrominated diphenyl ether (PBDE)																																																										
Host	x	○	○	○	○	○																																																										
Accessories	○	○	○	○	○	○																																																										
<p>1 Introduction</p> <p>1.1 Acknowledgement</p> <p>Thank you for choosing the sound blaster audio produced by our company. In order to let you experience the product easily, we have provided detailed instructions for use, from which you can get the knowledge of product introduction, usage methods, etc. Please read the instructions carefully before you use this machine. If there are printing errors or translation errors, we hope the users will understand.</p> <p>1.2 Matters Needing Attention</p> <p>Maintenance and Maintenance • Please keep the equipment dry. Do not expose the equipment to water and vapor. • Do not expose the equipment to strong impact or vibration, so as not to cause equipment failure. • Do not place this equipment in an area where the temperature is too high or too low, otherwise it may cause equipment failure. • Do not touch chemicals such as benzene and thinner. • Please keep the equipment away from magnetic field. • Please do not use light or heating equipment. • Do not listen at a high volume, so as to avoid adverse effects on listening. • Please do not disassemble, repair or modify the equipment without authorization, otherwise the equipment will not be covered by our warranty.</p> <p>1.3 Safety Instructions</p> <p>Before using the product, please read the information in this section and let your children know the information. For more detailed information, please refer to safety instructions and precautions. • Do not block any ventilation holes. • Do not approach any products that generate heat, such as radiators, stoves or other equipment. • Prevent the power cord from being walked on or pinched, especially at plugs, power sockets, and equipment power outlets. • Please unplug the power plug of this product during thunderstorms or when it is not used for a long time. • Do not disassemble the product and accessories without authorization. Only authorized organizations can repair the product. • Please keep the product away from magnetic equipment, the radiation of the product will erase the information stored on the magnetic equipment. • Do not place any dangerous sources (such as liquids, lit candles) on the machine. • Keep the accessories of the product out of the reach of children, and do not allow children to use the product without supervision. • When using this product, please abide by relevant laws and regulations, and respect the privacy and legal rights of others. • Please strictly follow the relevant instructions in this manual when using the external adapter, otherwise your product may be damaged.</p>	<p>2 Equipment Introduction</p> <p>2.1 Equipment Packaging List</p> <p>The following items are included in the box of your equipment: • Complete equipment * 1 • Adapter • 3.5mm audio cable * 1 • User manual * 1 (including three-in-one instructions/certificates/warranty cards)</p> <p>2.2 Energize Equipment</p> <p>Before using the machine, connect the external adapter with the DC interface of the device, and then plug it into the AC socket. • Be sure to connect the equipment with adapters distributed randomly. Adapters with mismatched specifications may burn out the equipment. Please select the charging adapter in strict accordance with the product specifications;</p> <p>2.3 Product Specification</p> <p>Adapter: 24V/2.5A RMS: 20W * 2+40W+80W Distortion: < 10% Signal to noise ratio: > 90db Frequency response range: 50Hz-20kHz Loudspeakers: 2*driver size:420*130mm), 20W 4Ω 1*driver size:420*130mm), 20W 4Ω 1*6.5 60W 4Ω</p>	<p>3 Product Specification</p> <p>3.1 Audio Key Function/Interface Function Description</p>  <p>Front panel: ① Power key, ② Mode key, ③ Play/pause key, ④ VOL +/next song, ⑤ VOL -/previous song Back panel: ⑥ HDMI interface, ⑦ AUX 3.5 interface, ⑧ USB interface, ⑨ Optical fiber interface, ⑩ Bass interface, ⑪ DC port</p> <p>3.2 Remote control function description</p>  <p>1. Press the start button to turn the device on and off 2. Press BT to quickly enter Bluetooth mode 3. Press aux to quickly enter aux mode 4. The volume plus or minus buttons can control the volume 5. The power key can turn the device on and off 6. Pause button. Press this button to control the pause of the equipment 7. Mute button. Press this button to control the equipment to turn off the indicator light 8. Led button. Press this button to control the equipment to turn off the indicator light 9. Bass button. Press this button to control the bass volume 10. Volume control key. Press this key to independently control the bass volume 11. Mode key, press this key to switch different sound source inputs 12. This remote control does not have RF function</p>	<p>3.3 Turn On and Off</p> <p>Power on: Press and hold the ● key for 2 seconds to power on the equipment. Shutdown: Press and hold the ● key for 2 seconds to shut down the equipment.</p> <p>3.4 Volume Adjustment</p> <p>Vol+: Press the + key briefly to increase the volume of the device. Vol-: Press the - key briefly to reduce the volume of the device.</p> <p>3.5 Bluetooth Play</p> <p>3.5.1 Bluetooth connection 1. Switch the audio to Bluetooth mode (short press M key to switch modes). 2. Turn on the Bluetooth device (mobile phone/tablet, etc.), search for the audio pairing name "SWC182T", click the pairing name to pair, and show that the connection is successful. 3. Long press the > key to disconnect and reconnect Bluetooth.</p> <p>3.5.2 Music playing 1. Click the > key to play or pause music. 2. Press – briefly to switch to the next song, and press + briefly to switch to the previous song.</p> <p>3.6 U Disk Play</p> <p>Under normal use mode, you can automatically switch to the USB flash drive playing function by directly inserting the USB flash drive. < Some models need to manually press the M key to switch to the USB flash drive mode to play. If it is not playing, please check whether there are MP3 media files in the USB flash drive. The file system format of the USB flash drive is FAT32, and the system format other than FAT32 is not supported for the time being. The USB flash drive supports up to 32G ></p> <p>3.7 AUX In</p> <p>AUX input with 3.5 and RCA input < some models only have one input > 1. Plug the AUX 3.5 audio cable into the device, and press the M key to switch to AUX 1 mode to play. 2. Plug the AUX-RCA audio cable into the device, and press the M key to switch to AUX 2 RCA mode to play.</p>	<p>3.8 OPTICAL In</p> <p>HDMI supports multiple modes and protocols, at present, our products only support ARC mode. ARC is called Audio Return Channel, which means audio return channel. Its function is to transmit sound signals. • Plug the device into the HDMI signal line and press the M key to switch to the OPTICAL mode to play.</p> <p>3.9 HDMI ARC</p> <p>HDMI supports multiple modes and protocols, at present, our products only support ARC mode. ARC is called Audio Return Channel, which means audio return channel. Its function is to transmit sound signals. • Plug the device into the HDMI signal line and press the M key to switch to HDMI mode to play.</p> <p>3.10 Bass Output</p> <p>External bass output interface, which can be used by external active subwoofer.</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>FCC warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.</p>																																																												
<p>4 QUICK INSTALLATION GUIDE</p> <p>01  Place the paper guide on the wall where you want to hang the bar.</p> <p>02  Verify with a level gauge that the inclination angle of the bar is zero degrees.</p>	<p>03  Locate the screw holes on the paper guide and mark a point with a pencil.</p> <p>04  Make the holes with the corresponding drill bit according to the type of wall.</p> <p>05  It is advisable to leave no more than 5 mm between the head of screw and the wall to minimize the inclination angle of the sound bar.</p> <p>06  For better sound experience it is advisable to place the sound bar at the same height of the ear.</p>																																																															