

User Manual

1. Product Overview

The circular wireless charger offers a sleek and hassle - free charging solution. Its circular design not only looks modern but also provides a stable base for your device during charging.

2. Specifications

- **Input:** 5V=1.1A, 9V=1.1A, 12V=1.67A
- **Output Power:** 5W/10W/15W
- **Charging Efficiency:** > 75%
- **Charging Distance:** 2-8mm
- **Qi version:** 1.2.4
- And many other smartphones, tablets, and wireless - charging - enabled accessories.

3. Package Contents

- 1 Circular Wireless Charger with a power connecting cable

4. Compatibility

This wireless charger is compatible with most Qi - enabled devices

5. How to Use

5.1 Connect to Power

Connect the provided, male plug of the power connecting cable to the female plug of the power-source cable.

5.2 Place Your Device

Put your Qi - enabled device in the center of the circular charging pad. Make sure the back of the device touches the charger surface directly. Avoid using thick cases, metal objects, or magnetic accessories between the device and the charger for best results. Some devices have a specific wireless - charging area; try to align it with the center of the charger.

6. Charging Tips

- **Optimal Placement:** Keep your device centered on the charging pad. Moving it during charging may stop or slow down the charging.
- **Avoid Obstructions:** Take off thick cases, metal phone holders, or magnetic cards from your device before charging. These can interfere with charging and may cause overheating.

7. Safety Precautions

- **Overheating:** If the charger or device gets too hot during charging, remove the device immediately and let them cool down. Overheating can be due to a malfunction, blocked charging area, or charger problem. Don't use the charger if it overheats often.
- **Moisture and Water:** Keep the charger away from moisture, water, and humid places. Don't expose it to rain or spill liquids on it. If it gets wet, unplug it and let it dry completely before using again.
- **Foreign Objects:** Don't put foreign objects, especially metal, on the charger. Metal can cause short - circuits and damage the charger or device. Also, keep magnetic objects away as they can interfere with charging.
- **Children and Pets:** Keep the charger and accessories out of reach of children and pets. Small parts like the USB cable can be a choking hazard for children.
- **Do Not Modify:** Don't try to take apart, modify, or fix the charger yourself. Tampering voids the warranty and can be dangerous. If the charger isn't working, contact customer support.

8. Maintenance and Cleaning

- **Regular Cleaning:** Clean the charger regularly with a soft, dry cloth to keep it in good condition. Wipe the surface gently to remove dust, dirt, and fingerprints.
- **No Harsh Chemicals:** Don't use harsh chemicals, abrasive cleaners, or alcohol to clean the charger. These can damage the surface and affect performance.

9. Troubleshooting

- **Device Not Charging:**
 - Check if the charger is properly connected to the power source. Try a different outlet.
 - Make sure your device supports Qi - wireless charging. If not, you may need a wireless - charging receiver.

- Check for obstructions between the device and charger. Remove cases, metal objects, or magnetic accessories.
- Try re - positioning your device on the charger. Ensure it's centered and in good contact.
- **Slow Charging:**
 - Check if your device supports fast charging.
 - There may be interference from nearby electronics. Move the charger and device away from Wi - Fi routers, microwave ovens, and Bluetooth speakers.

10. Warranty Information

This circular wireless charger has a 1 - year warranty against manufacturing defects. If you have problems during the warranty period, contact our customer support with your proof of purchase. The warranty doesn't cover damage from misuse, abuse, or unauthorized modification.

11. FCC compliance statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.