

RXF-40 Manual

Instructions for power supply operation :

1. The radio already contains 18650 lithium rechargeable battery, which can be plugged into DC socket for charging or used directly.
2. When the radio is not used for a long time, please unplug all power plugs.

Instructions for radio use:

Turn on the "OFF/ON TUNING KNOB" , push the knob to increase the volume, then pull out the antenna. It will automatically play the searched channels, press "  " to play the previous radio, press "  " to play the next radio.

Instructions for the use of USB/TF card:

Turn on the "OFF/ON TUNING KNOB", push the knob to increase the volume, and then insert the U disk or TF card with MP3 songs into the radio, the music will be played automatically. If you want to choose to play U disk, TF card or Bluetooth, just press the "MODE" button to convert. Press the "  " or "  " button to select previous and next songs. Press and hold these two buttons for 3 seconds, the song can be played back or forward quickly. And the playback can be paused by pressing the "  " button.

Instructions for Bluetooth music playback:

1. Turn on the "OFF/ON TUNING KNOB", push the knob to increase the volume, press "MODE", after hearing the Bluetooth prompt sound, turn on the Bluetooth function of the mobile phone to pair and connect with the Bluetooth name "FP-BT".
2. After the connection is successful, you can open the mobile phone player to play music.

3. To select a song, press the "◀◀" or "▶▶" button to select up and down songs, and press the "▶⏸" button to pause playback.

Instructions for the use of AUX IN:

Turn on the "OFF/ON TUNING KNOB", push the knob to increase the volume, and plug the other end of the AUX connection cable into the "AUX IN" input port to play music.

Press the "▶⏸" button to mute. Press the "MODE" button to switch the Bluetooth connection.

Instructions for the use of LED light:

Long press "LIGHT" button to turn on or off the LED light. The brightness of the light can be adjusted in three levels. Continue to press the "LIGHT" button to adjust the light level 1-3.

Instructions for the use of Fan:

Turn on "▶" knob to turn on the fan. Continue to turn the knob to adjust the fan wind level.

Instructions for the use of Remote control:

After turn on the "OFF/ON TUNING KNOB" or "▶" knob , the remote control can be used to control all functions of the radio, including turning off the power.

NOTE:

1. THIS MODEL INCLUDES BUILT IN RECHARGEABLE BATTERY.
2. IN ORDER TO PROLONG BATTERY LIFE AND PRODUCT NORMAL USE, PLEASE KEEP CHARGING TIME FOR 6-8 HOURS.

Remote control manual

1. After turn on the "OFF/ON TUNING KNOB" or "red" knob, press the "3" button to turn on the fan. Fan has 3 levels of wind adjustable, continuous press "3" button can be 1-3 levels of wind enhanced adjustment. Continuously press the "2" button to reduce the wind until the fan is turned off.
2. After turning on the "OFF/ON TUNING KNOB" or "red" knob, press "11" button to turn on the LED light. LED light has 3 levels of brightness adjustable, continuously press "11" button to make 1-3 levels of brightness enhancement adjustment. Continuously press the "10" button to reduce the brightness until the LED light is turned off.
3. Number buttons on the remote control for MP3 song selection.
4. The other function buttons on the remote control have the same function as the buttons on the radio.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction