

# Lunar-Shaped Speaker



## USER GUIDE

FS310

To ensure proper operation and avoid damage, please read this user manual carefully before using the product.

## Features:

**Lunar-Shaped Design with Essential Oil Diffuser: Combines aesthetics with functionality.**

**Bluetooth Speaker:** High-fidelity sound quality with stable wireless connectivity.


**Moonlight Lamp:** Adjustable soft ambient lighting mimicking the lunar glow. Brightness is customization.

**Gypsum Aroma Diffuser:** Made from natural gypsum material for safe and efficient fragrance diffusion.

**Eco-Friendly Acrylic Material:** Transparent and pure, ensuring an environmentally conscious design.

**Multi-Sensory Experience:** A stylish and minimalist home decor item that integrates a speaker, lighting, and diffuser, offering a harmonious experience for sight, hearing, and smell.

## Product Overview:



1. **Power On/Off; Play/RGB Light Control**
2. **Volume Up/Backward**
3. **Volume Down/Forward**
4. **Bluetooth/White Noise Mode**
5. **USB-C charging port**
6. **Charging indicator**

#### **Power On/Off:**

Press and hold the Power button to turn the speaker on or off.

#### **Auto Power Off:**

The speaker will automatically power off under the following conditions:

- When in Bluetooth mode, if no mobile device connects within 10 minutes.
- When in Bluetooth mode, if no music is played for more than 10 minutes.
- When in White Noise mode, the speaker will power off after 30 minutes.

#### **Bluetooth Mode:**

1. Turn the speaker on by pressing the Power button. The speaker will automatically enter Bluetooth mode, indicated by a slowly blinking blue light.
2. Activate Bluetooth on your mobile device and search for "FS310" to connect. Once connected, the blue light will remain steady.
3. Play music from your mobile device and enjoy.
4. **Song Selection:** Press and hold the Forward or Backward button for 2 seconds to skip tracks.

5. **Volume Control:** Press the Forward or Backward button to adjust the volume.
6. **Factory Reset:** Press and hold the Backward button "-" for 8 seconds to restore factory settings.
7. **Light Mode:** Press the Power button to switch between different light modes.
8. **Mode Switching:** Press the Mode button to switch between Bluetooth mode, White Noise mode, and loop playback.
9. **Disconnect Bluetooth:** Press and hold the Mode button for 2 seconds to disconnect from the current Bluetooth device.

#### **White noise mode:**

1. **Song Selection:** Press and hold the Forward or Backward button for 2 seconds to skip tracks.
2. **Volume Control:** Press the Forward or Backward button to adjust the volume.
3. **Factory Reset:** Press and hold the Backward button "-" for 8 seconds to restore factory settings.
4. **Light Mode:** Press the Power button to switch between different light modes.
5. **Mode Switching:** Press the Mode button to switch between Bluetooth mode, White Noise mode, and loop playback.

#### **RGB Light control:**

1. Press the Power button to switch between lighting effects:
  - Mode 1:** Warm color always on.
  - Mode 2:** Steady white light.
  - Mode 3:** Light off.

2. Double-click the Power button to adjust the light brightness across three levels.

### **Reset Functionality:**

If the speaker becomes unresponsive or fails to power off, press and hold the "-" button for 8 seconds to reset the speaker and power it off.

### **Additional Notes:**

- The default volume is set to 30% of the maximum volume.
- Playtime may vary depending on volume level and music style.

### **Charging Instructions:**

**Charger Not Included:** Please use a rated 5V/1A or 5V/2A charger to charge the speaker.

**Charging Time:** Approximately 3 hours. The charging indicator will glow red during charging and turn off once fully charged.

**Low Battery Alert:** The speaker will prompt you to recharge when the battery voltage is low.

**Safety Note:** To protect the battery, avoid using the speaker while it is charging.

### **Warning:**

**Temperature:** Store and use the product in a normal temperature environment.

**Moisture:** Avoid exposing the product to rain or moisture.

**Unauthorized Repairs:** Do not disassemble, repair, or modify the product without authorization.

**Cleaning:** Use a soft cloth or a slightly damp cloth for cleaning. Avoid using chemicals.

**Volume:** To protect your hearing and extend the product's lifespan, avoid listening at maximum volume for extended periods.

**Battery Safety:** The product contains a built-in lithium battery. Do not discard it in fire or expose it to high temperatures.

### **Warranty:**

This product comes with a 1-year limited warranty.

### **FCC STATEMENT**

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and

used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this

equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.