

Product Manual for Ceiling Fan Light Remote Control

Product Overview

Thank you for choosing our ceiling fan light remote control. This remote operates at a frequency of 303.875Mhz and is powered by an A23/A27 battery, with a normal operating voltage range of 7.5V-12.6V. There are four variations of the remote, primarily differing in button configurations: the most comprehensive model features dual buttons for dual light control, along with three buttons for the ceiling fan's high, medium, and low speeds, plus a fan off button and a fan reverse button. Other models vary in single/dual light control and the presence of a reverse button. All light buttons support long-press dimming, while other buttons are touch-sensitive.

Product Overview

Ceiling Fan Control

High/Medium/Low Speeds: Three buttons control the fan's speed settings.

Off Button: Turns off the ceiling fan.

Reverse Button: During specific seasons or conditions, this button reverses the fan blades' rotation direction.

Light Control

Single/Dual Light Control: Depending on the remote model, it can control one or two lights independently or simultaneously.

Long-Press Dimming: Long-pressing the light buttons adjusts the light brightness.

Battery & Voltage

Powered by an A23/A27 battery.

Normal operating voltage range is 7.5V-12.6V.

Dip Switches

A 4-digit dip switch on the back of the remote must match the settings on the ceiling fan controller.

No pairing or learning required; ready for use.

LED Indicator

The LED indicator lights up when a button is pressed.

Usage Precautions

Ensure that the dip switch settings on the remote and ceiling fan controller match.

Replace batteries with the same type when needed.

Avoid using the remote in damp or high-temperature environments.

If the remote malfunctions, check the battery life and dip switch settings.



LED Indicator:

The LED indicator lights up when a button is pressed.

Single/Dual Light Control:

Depending on the remote model, it can control one or two lights independently or simultaneously.

Long-Press Dimming: Long-pressing the light buttons adjusts the light brightness.

High/Medium/Low Speeds:

Three buttons control the fan's speed settings.

Off Button:

Turns off the ceiling fan.

Reverse Button:

During specific seasons or conditions, this button reverses the fan blades' rotation direction.



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.