

5. FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement (Car): To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF Exposure Statement (Controller): The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Manufactured by / Packed by / Marketed by & Customer Care Executive Address:

MIRANA INNOVATIONS PRIVATE LIMITED

719, Warehouse-5, Titanium Logistics Park, Rajoda, Bavla, Ahmedabad,
GJ, India - 382 220.



www.miranatoys.com



SPIKER

APP & REMOTE CONTROL SMART TOY



BLUETOOTH®
SPEAKER



AR GAME
COMPATIBLE



PRE-LOADED
ENGINE SOUND



SPEAKER VOLUME
CONTROL



1.5X NITRO
SPEED BOOST



C-TYPE
USB CHARGING



RECHARGEABLE
BATTERY



ALL-TERRAIN
TYRES



VARIABLE SPEED
REMOTE CONTROL



DURABLE
MATERIAL



HIGH TORQUE
MOTOR



FOR AGES
4 & ABOVE

WELCOME

Enjoy the flexibility of controlling your Smart Toy using both the dedicated Mirana Mobile App and the included remote control. Choose the method that suits your play style and switch seamlessly between them.


Please read this document and the safety instructions carefully before using the all-new smart toy car.

www.miranatoys.com

1. BUILT-IN BATTERY

The toy comes with a rechargeable 2000 mAh battery. Don't attempt to modify, remove or replace the battery as it may damage it and cause overheating and injury. Don't cut, tear, puncture, compress or deform the toy by disassembling it. Follow the below instructions for charging its battery:

1. Turn the toy upside down to check the charging port.
2. Plug the USB charging cable provided in the box into the (5V-2A) DC input charging slot at the bottom of the toy.
3. Red LED will glow up while charging.
4. Green LED will glow up when the toy is fully charged.
5. Remove the adapter when the Green LED glows up.
6. The toy will not charge if it is on. To charge switch off the toy first.



2000 mAh Rechargeable Li-Ion Battery (Included)


2. APP PLAYING INSTRUCTIONS

1. Download the "Mirana" App from the Google Play Store or the App Store for Android and iOS devices, respectively.
2. Turn on the power switch of the toy given its bottom.
3. Switch on the Bluetooth® of your mobile phone and open the Mirana App installed on your phone.
4. Click on the "Add Toy" button in the Mirana App.
5. Click on the toy in the App to pair it and set a name.
6. Your toy and the Mirana App are now connected. Click on any game to start.
7. For directional control, use the left round button on the console screen to move the vehicle forward and backward. Use the right round button to turn left or right.
8. For an extra burst of speed, you can use the (energy symbol) button to activate the Boost function.

9. To exit the game press on the pause button in top right corner.

3. REMOTE PLAYING INSTRUCTIONS

1. Turn on the remote and turn on the car. The lights will stop blinking when the remote is connected.
2. For directional control, use the left joystick on the controller to move the vehicle forward and backward. Use the right joystick to turn left or right.
3. For an extra burst of speed, use the "UP" button to activate the Boost function.
4. The "Down" button can be used to turn on / off the Engine Sound.



5. Use the "Right" button to perform the Stunt Next and the "Left" button to perform the Stunt Previous.
6. While the car is in motion, you can use the "Right" button to drift the car to the right, and the "Left" button to drift the car to the left.
7. To activate the horn, Press the "Center" button.
8. Press the "Horn" button with the "Stunt Next" button to increase the volume, and press the "Horn" button with the "Stunt Previous" button to decrease volume.

4. SAFETY PRECAUTIONS

The toy should be used by children aged 4 years or above. While using it for the first time, this toy car should be safely set up under adult supervision. Do not try to modify any part of the toy, which may negate your authority to use it. Rechargeable batteries of this toy car should be charged under adult supervision only. While charging the toy, do not touch the electric outlet and the charging port with bare/wet hands to avoid electric shock. Adults should examine the USB cable, plug, enclosure or other parts of the toy regularly. Do not immerse the toy or any part of it in water to clean it. This can damage its electronic components.