

英文说明书

正面




GOOD One wireless charging desk lamp


1. Product Information

Product Name : GOOD One wireless charging desk lamp
Product Model : NO-HB051(Beech) NO-HB052(Sapele)
Light Source : LED
Color Temperature : 5000K Natural Light
Power : 2.4W
Reference Illumination : About 460lux
(Test with long-bright mode 10cm away from the lampshade)
Battery Capacity : 1100 mAh lithium battery
Charging Time : About 4.5H(Wired Charging)
Battery Life : About 17H(Long bright mode)
Voltage DC5V 2A
Product Material : Solid wood, Plastic, Electronic components
Accessories : Light x1, Lamp post x1, Base x1, Magnetic sheet x1, Charging cable x1
Product Size : 163 x 80 x 386mm
Package Size : 95 x 50 x 310mm
Gross Weight : 420grams
Implementation standards
GB7000.204-2008 GB7000.1-2015


2. Standard Configuration



3. Product Structure



4. Installation Instruction




背面

5. Operation Instruction

Touch switch
Touch to turn on/off the light
Long press to adjust the light intensity

Light angle adjustment
360° free adjustment angle

One lamp for multiple purposes




Charge

2 charging methods are designed, wire charging and wireless charging.


① Wireless charging

Wireless charging base, the power is within 10 watts. Plug the power cord into the base to input power. At this time, the wireless charging indicator light turns blue. Align the icon on the back of the lamp body with the charging indicator light of the wireless charging base. Wait for about 2-5 seconds. When the charging indicator light on the light-emitting surface of the lamp body lights up red, it means that the wireless charging is charging normally. After it is fully charged, the indicator light will automatically turn off.



② Wire Charging

Under normal charging status, the indicator light is red
Full charge indicator is off



90mm

Tips

- The power supply current of the adapter corresponding to the wireless charging base must be above 2A, otherwise it will affect the normal charging effect.
- When the table lamp is charging, if the indicator light does not light up red, or the indicator light flashes, it means that the wireless charging position is incorrect and should be re-aligned.
- The wireless charging table lamp is also compatible with charging mobile phones, smart watches and other devices with wireless charging functions.

157mm

CERTIFICATION : Product Quality: A : Inspector: 02

Adapter Power Bank Computer Laptop

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.