


## JR1839FCC Remote Control Manual

- (1). Supply Voltage—DC 3.0V , Battery 2\*1.5V AAA (not included)
- (2). Frequency 2.407GHz-2.473GHz (Peak output power: 5dBm)
- (3). Instructions



- a. Frequency binding is required for the first use, this product has memory function  
Replace battery is unnecessary Frequency binding.
- b. Hold down " M " key for 3 seconds start Frequency binding, The LED flicker
- c. Turn on the vehicle power now, The LED stop flicker, Frequency bind Success
- d. Remoter 10 seconds not run will be standby ,Press any key will be wake up
- e. Keys caption : "  $\Delta$  " Forward,"  $\nabla$  " Back,"  $\triangleleft$  " Left,"  $\triangleright$  " Right," " S "Speed," " P " Brake.  
Press " S " key set up speed , 1 led lit up is low speed , 2 leds lit up is medium speed ,  
3 leds lit up is high speed.  
Press " P " key hold the brake, All LED flicker

※ The remote controller only can be used with adult's guidance

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.