



# **AUGI Gem User Manual**

**Model: IN6A008**

FCCID: 2BNIV-GEM-1



# How AUGi Gem Works

AUGi Gem is an IoT device that helps caregivers continuously monitor resident activity throughout a senior living facility.



## HW I/O Specification

Specification	Description
Power	12V DC
Button	Single press for reset
LED	Status
Wireless Transceiver	WLAN: 2.4 and 5 GHz Bluetooth Lora



# Setting up AUGi Gem

## Unpacking AUGi Gem

- Included:
  - AUGi Gem
  - Power supply unit
  - Power cable
  - Mounting bracket (with mounting hardware)

## Install Requirements

- Access to the designated installation software
- Location and orientation determined by installer at time of installation
- Considerations
  - Visual (Moveable Curtains, Mounted TVs, Moveable Equipment)
  - Radio Frequency (Wireless Networking Equipment or Similar)
  - Noise (HVAC Vents)
  - Heat Sources (TVs, Networking Equipment)
- Wall Mounted with the included mounting bracket and hardware

## Install Instructions

- Secure the mounting bracket to the wall using provided screws into a beam/stud (or use wall anchors for drywall).
- Slide the AUGi Gem onto the bracket until safety latch clicks

# Using AUGi Gem

Once it is mounted, powered, and connected, AUGi Gem runs continuously without requiring user interaction. Caregivers use the mobile or web applications to receive status and alerts from AUGi Gem.

## FCC Compliance Statement

### FCC ID: 2BNIV-GEM-1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and



(2) this device must accept any interference received, including interference that may cause undesired operation.

---

### **FCC Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
  - Increase the separation between the equipment and receiver
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
  - Consult the dealer or an experienced radio/TV technician for help
- 

### **FCC RF Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device should be installed and operated with a minimum distance of **20 cm** between the radiator (antennas) and all persons.

The transmitter must not be co-located or operating in conjunction with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures.

---

### **15.21 Information to user**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



### **Labeling Notice**

The FCC ID is located on the rear of the product enclosure. It is not accessible to the user for removal or alteration.