





<div>无线快充车载支架</div> <div>使用说明书</div>	<div>参数说明</div> <div>产品名称：无线快充车载支架（智能感应款）</div> <div>功率：15W/10W/7.5W</div> <div>有效传输距离：0-5mm</div> <div>尺寸:112mm*69mm*44mm</div> <div>充电接口：TYPE-C</div>	<div>功能组件</div> <div></div>	<div>规格参数</div> <div>1.重量：产品净重约212g</div> <div>2.材质：ABS+PC+镁铝合金</div> <div>3.输入电压/电流：5V/2A.9V/1.67A</div> <div>4.磁吸头输入电压：DC 5V/2A</div> <div>5.输出功率：15W/10W/7.5W自动识别</div> <div>6.充电频率：110K-205KHz</div> <div>7.充电距离：0-6mm</div> <div>8.支持QC无线快充的设备，如iphone 15系列,iphone 14系列，iphone 13系列,iphone 12系列,iphone 11系列，iphone XS Max,iphone XR,iphone X,iphone 8,iphone 8X，华为 Mate 60系列，Mate 50系列，Mate 40系列，Mate 30系列，Mate 20系列，P50 Pro,P40 Pro,P30 Pro,SAMSUNG Galaxy系列，S8-S20系列,Note8-10系列等支持无线充电手机</div> <div>9.不支持无线快充的设备，可根据设备充电接口使用相对应的磁吸头，方可使用；或者购买符合Qi标准接收器即可使用</div>	<div>使用说明</div> <div>1.使用时将本产品连接适配的数据线</div> <div>2.将数据线的USB端连接车上接口（如：点烟器转换器及USB充电接口）</div> <div>3.底座夹子夹住空调出风口，也可放置其他可扣夹的地方</div> <div>4.设备接通5~9V直流电源后，自动检查张合一次，指示灯亮起，当物体靠近设备5cm-20cm时，自动感应并张开双臂，放入手机，设备自动夹紧手机，此时，无线快充将对手机自动充电（手机具备无线充电功能）。取出手机时需要触摸正面触摸开关或者背面下角手指图标感应区，当手指触碰到此位置时，设备自动张开双臂，取走手机。</div> <div>5.本设备内置过压保护，过温保护，磁场保护，短路保护。如出现异常时，会自动停止工作</div>	<div>注意事项</div> <div>1.请勿过度挤压或碰撞设备</div> <div>2.请勿在严重高温、潮湿或腐蚀性的环境下使用本产品，避免损坏设备的电路</div> <div></div> <div>感谢您使用本产品!</div>
--------------------------------------	---	--	---	--	---

<div>Wireless Quick Charging Vehicle Holder</div> <div>Instruction Manual</div>	<div>Parameter Description</div> <div>Product Name: wireless fast charging vehicle holder (intelligent induction type)</div> <div>Power:15W/10W/7.5W</div> <div>Effective transmission distance:0-5mm</div> <div>Host size:112mm*69mm*44mm</div> <div>Charging interface: TYPE-C</div>	<div>Functional components</div> <div></div>	<div>Specifications</div> <div>1. Weight: about 212g</div> <div>2. Material: ABS+PC+magnesium aluminum alloy</div> <div>3. Input voltage/current: 5V/2A.9V/1.67A</div> <div>4. Input voltage of magnetic suction head: DC 5V/2A</div> <div>5. Output power: 15W/10W/7.5W automatic recognition</div> <div>6. Charging frequency: 110K-205KHz</div> <div>7. Charging distance: 0-6mm</div> <div>8. Devices that support QC wireless fast charging, such as iPhone 15 series, iPhone 14 series, iPhone 13 series, iPhone 12 series, iPhone 11 series, iPhone XS Max, iPhone XR, iPhone X, iPhone 8, iPhone 8X, Huawei Mate 60 series, Mate 50 series, Mate 40 series, Mate 30 series, Mate 20 series, P50 Pro, P40 Pro,P30 Pro, SAMSUNG Galaxy series, S8-S20 series,Note8-10 series and others support wireless phone charging</div> <div>9. Devices that do not support wireless fast charging can be used according to the device charging interfaceThe corresponding magnetic suction head can only be used; Or purchase Qi compliant connectorsThe receiver is ready to use</div>	<div>Instructions For Use</div> <div>1. Connect the product to the appropriate data cable during use</div> <div>2. Connect the USB end of the data cable to the vehicle interface(e.g. cigarette lighter converter and USB charging interface)</div> <div>3. The base clamp clamps the air outlet of the air conditioner, and can also be placed in other places that can be clamped</div> <div>4. After the equipment is connected with 5 ~ 9V DC power supply, it will automatically check the tension and closing once,The indicator light is on. When the object is 5cm-20cm close to the equipment, it will automaticallySense and open your arms, put in the mobile phone, and the device automatically clamps the mobile phone,At this time, the wireless fast charging will automatically charge the mobile phone (the mobile phone has wirelessA charging function). When taking out the phone, it is necessary to touch the front touch switch or the bottom finger icon sensing area on the back. When the finger touches this position, the device automatically opens its arms and takes away the phone.</div> <div>5. The equipment has built-in overvoltage protection, over temperature protection, magnetic field protection and short circuitProtection. In case of abnormality, it will automatically stop working</div>	<div>Precautions</div> <div>1. Do not over squeeze or collide with the equipment</div> <div>2. Do not use it under severe high temperature, humidity or corrosive environmentThis product can avoid damaging the circuit of the equipment</div> <div></div> <div>Thank you for using this product!</div>
---	--	---	--	---	---

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.