


STUNT ROBOT DOG

Mechanical technology

Instructions

Thank you for using our company's toy products. In order to give you a better understanding of this product, please read the following instructions carefully before use. This will bring you a different operating experience.


Product Configuration



Dual remote control instructions



Charging and installation instructions for remote control car batteries



2.4G automatic code matching instructions

- After installing the battery on the remote control, the indicator light on the remote control starts flashing. When the battery is installed on the remote control car and the switch is turned on, the colorful light flashes. Start entering the connected state. When the connection is successful, the remote control indicator light goes out and the car's colorful lights are in a breathing state. When the festival is successful, turn off the power switch of the car when not playing.
- Each remote control can only be connected to one remote control vehicle, and once successfully connected, each vehicle will not interfere with each other. Note: Cannot be excessive. Connect all vehicles simultaneously.
- If the remote control does not detect the 2.4G signal emitted by the car when powered on after one minute, it will automatically enter sleep mode (Press any key to exit sleep mode when the indicator light is off).
- When pairing with other remote controllers or remote control vehicles of the same model, the remote control and remote control vehicle power must be turned off before re pairing.

Precautions for remote control products

- The remote control car uses one set of 3.7V rechargeable batteries; The remote control uses 2.1.5V "AA" non rechargeable batteries;
- The battery should be removed and inserted correctly according to the polarity and voltage markings on the toy battery box, and the battery should not be short circuited;
- Only use batteries that are the same or identical to the recommended ones;
- Do not mix old and new or different types of batteries;
- Non rechargeable batteries cannot be charged;
- Rechargeable batteries should be removed from toys before charging;
- The exhausted battery should be removed from the toy. If it is not used for a long time, please remove the battery from the toy;
- Rechargeable batteries must be charged under adult supervision;
- The power terminal shall not be short circuited;
- Cannot connect to more than the recommended number of power sources.
- The battery charger should be regularly inspected for damage to its wires, plugs, casing, and other components. If damage is found, it should be stopped from use until it is repaired.

Under normal circumstances, fault handling

Fault symptoms	Reason for malfunction	Processing method
The vehicle cannot be driven	1. The remote control is not connected or the remote control car's switch is not turned on. 2. The remote control or remote control car is not properly equipped with batteries. 3. The rechargeable battery pack has insufficient power.	1. Turn on the remote control car switch and reconnect the remote control. 2. Install the battery correctly into the remote control or remote control car. 3. Charge the rechargeable battery pack.
The vehicle is not under control and the remote control distance is close	1. The power of the battery or rechargeable battery pack inside the remote control is insufficient. 2. There may be interference sources near the venue.	1. Replace the battery inside the remote control with a new one or charge the rechargeable battery pack. 2. Change the venue.
Abnormal protection	1. When the remote control car function is obstructed by external forces and cannot complete all functions, or when the circuit battery is short circuited.	1. Turn on the power switch again and remotely control the car for power-off protection

How to play remote control car

- Turn on the remote control car switch
- Operate the directional lever of the remote control to remotely control the car to move forward or backward, left or right.
- After use, turn off the remote control car switch.
- When the play is over, just turn off the remote control car switch. The remote control will automatically enter sleep mode.

Instruction Description

Regularly inspect to prevent damage to wires and other components. If damaged, it must be repaired before use.

Maintenance matters

- Do not approach fire sources, avoid direct sunlight, high temperature and humidity, or keep in the car for a long time. Can prevent short circuits and fires in the circuit.
- Remove the batteries from the car and remote control when not in use. And return the remote control car and remote control to the packaging box. It can avoid damage or deformation during transportation or storage.
- The remote control car should be gently wiped with a damp cloth.

FCC Statement

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

13. The remote control car should be gently wiped with a damp cloth.