

JL0532-01 Bluetooth Headphones

User Manual

Contents

1. Introduction
2. Operation
3. Troubleshooting
4. Precautions
5. Specifications

1. Introduction

Welcome to the JL0532-01 Bluetooth Headphones! This manual provides detailed instructions on how to operate and maintain your headphones. Please read this manual carefully before using the product to ensure optimal performance and safety.

2. Operation

Power On / Power Off

Power On: Press and hold the POWER “” button for approximately 2 seconds. The blue LED will flash with a voice prompt “power on.”

Power Off: Hold and press the POWER “” button for approximately 5 seconds. The red LED will flash with a voice prompt “power off.”

Pairing

FirstTime Pairing: In the power off state, press and hold the POWER “” button for approximately 6 seconds until the red and blue LED lights flash alternately. Note that the light will turn blue first, but you must continue holding the “” button until both lights flash. Search for the pairing code on your phone's list and select it to pair. The pairing code is BSNCH102.

Connection Mode: Under connection mode, press and hold the POWER “” button for approximately 3 seconds. You will hear a voice prompt “ready to pair.” If you do not need to connect to another device, press and hold the POWER “” button for 2 more seconds to power off the headphones.

Automatic Reconnect: When powered on, the headphones will automatically reconnect with your phone. You do not need to enter pairing mode for re-connection.

Note: The headphones will power off automatically after 5 minutes if there is no connection.

HandsFree Call

Answering Calls: Click the POWER “ $\triangleright\|$ ” button to answer incoming calls. Ending Calls: Click the POWER “ $\triangleright\|$ ” button to hang up. Redialing Last Call Number: Double click the POWER “ $\triangleright\|$ ” button to redial the last call number.

Volume Control

Increase Volume: Click the “ $\triangleright\triangleright+$ ” button.
Decrease Volume: Click the “ $-\triangleleft\triangleleft$ ” button.

Previous/Next Song

Previous Song: In music mode, press and hold the button “ $\triangleright\triangleright+$ ” button.
Next Song: In music mode, press and hold the button “ $-\triangleleft\triangleleft$ ” button.

Pause/Play

Click the POWER “ $\triangleright\|$ ” button to play or pause music.

ANC Control

Shift the ANC power button to turn on or off the ANC (Active Noise Cancellation) function “ON OFF”.

Charging

Insert the charging cord into the USB slot and plug the other end into a USB outlet or computer. The red LED light will stay on during charging. When fully charged, the blue LED light will be on.

Wired Headphones Function

When the headphones are powered, they can be used as wired headphones by inserting the 3.5mm audio cable.

3. Troubleshooting

1. Buttons and Microphone Don't Work: All buttons, including the microphone, will not work when the 3.5mm audio cable is inserted, except for ANC. Adjust the volume on your phone or other devices. The microphone only works in wireless mode.
2. Device Can't Sync with Headphones: In the power-off state, press and hold the POWER "▷||" button for approximately 6 seconds until the red and blue lights flash alternately to enter pairing mode. The headphones cannot sync with devices that do not have wireless function. An additional wireless transmitter (not included) is required.
3. Headphones Can't Be Turned On: Charge the headphones first. Hold the POWER "▷||" button for 2 seconds to turn them on.
4. Check Distance and Interference: Ensure the distance between the headphones and the mobile phone is not more than 10 meters and there is no interference.

4. Precautions

1. Volume Control: Before turning on the power of a connected device, turn the volume all the way down. A sudden burst of loud sound could be harmful to your ears and cause hearing loss.
2. Cable Removal: Be sure to hold the plug when unplugging the cable.
3. Interference with Other Devices: Do not use the headphones near medical devices, automatic doors, or fire alarms, etc. Signals from the headphones could interfere with the operation of these devices, possibly causing malfunctions and accidents.
4. Bracket Usage: Do not pull the headphone bracket more than 45 degrees and do not twist the bracket.

5. Specifications

Product Dimensions:

Product Net Weight:

Buttons

1. Power Indicator Light/ANC Lamp
2. Microphone Hole
3. 3.5mm Audio Cable
4. Micro USB Slot
5. ANC Switch Button
6. Volume Down/Next Song
7. Power Button
8. Volume Up/Previous Song

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.