


## 正面

**NoteSee**



**NS22**  
WIRELESS HEADSET

**Preface**

Dear user, thank you for purchasing our company's products. Before using this product, please read this manual carefully. Please make sure to keep this manual safe for future reference. All content has been carefully written by our company. If there are any printing or omission issues or errors, please understand.

**Precautions**


- Do not use this machine in extremely hot, cold, dusty, and humid environments.
- Do not drop, impact, or vibrate violently during use.
- Changes due to product performance and functionality will be notified separately.
- The earphones contain batteries and should not be exposed to direct sunlight, fire, or similar overheating environments.
- Please do not disassemble this machine without authorization to avoid danger.

**Structural schematic diagram**

1. Battery compartment



**2. Headphones**



**Function Description**

- Power on: The charging case is opened, and the earphones automatically start and pair.
- Power off: Place the earphones into the charging compartment, close the charging compartment cover, and the earphones will automatically shut down and charge.
- Answer/hang up: During a call or call, double-click the MFB button on either side of the earphone to answer/hang up the call.
- Refuse call: When receiving a call, press and hold the MFB button on either side of the earphone for 3 seconds.
- Play/Pause: Double click the MFB button on either side of the headphones.
- Switch songs: Press the MFB key three times on the left ear to switch to the previous song, and press the MFB key three times on the right ear to switch to the next song.
- Adjust volume: Click the left ear MFB button to decrease the volume, and click the right ear MFB button to increase the volume.
- Wake up voice assistant: Long press the MFB button on the left or right earphone for 3 seconds.

**Earphone pairing**

**First pairing method:**

- Take out two earphones, tear off the isolation film on the charging contacts of the earphones, then put the two earphones back into the charging case, close the charging compartment cover, and reopen the cover (this step is the activation step for the new device)
- Take out two earphones again
- Open the list of wireless devices on your phone, find NS22, click on pairing, and complete the pairing.

**Frequently Asked Questions and Answers**

- How to solve the problem of only one earphone having sound? Answer: Put the two earphones back into the charging compartment, close the cover, reopen the cover and wait for 2-3 seconds, then remove the earphones again and check if both ears have sound. If only one earphone still has sound, please reset the two earphones to factory settings (reset method: click the MFB button on the left and right earphones 5 times)
- How to solve the problem of phone prompt unable to connect? Answer: Delete the pairing record on your phone, then search for the name again and click on the pairing link.
- The earphones will automatically shut down if they are not connected for more than five minutes. How can I turn them on? Answer: Put the headphones back into the charging compartment, close the cover and then open it, take out the headphones and they will automatically turn on.
- How to solve the problem of stuttering/intermittent/delayed sound. Answer: If there is a large amount of WiFi, 4G, 5G signals, high-power appliances, etc. causing interference during use, it may cause lag, interruption, etc. It is recommended to change the environment or re-pair the connection to solve the problem

## 反面

**5. Automatic shutdown**  
Answer: After successfully connecting the earphones to the phone, if the earphones are away from the device for more than 5 minutes, the earphones will automatically shut down;  
2. If the earphones are not connected to the phone after 5 minutes, they will automatically shut down.

**Packaging List**

Charging compartment \*1      Earphones (L&R) \* 2  
Type-C charging cable \* 1      Instruction manual \* 1

**Charging instructions**

1. Open the earphone battery compartment cover, the display screen will show the battery level of the battery compartment, and then charge the charging compartment according to the value (it is recommended to charge the battery compartment in a timely manner if the value is less than 30). Open the earphone battery compartment cover, the display screen will show the battery level of the battery compartment, and then charge the charging compartment according to the value (it is recommended to charge the battery compartment in a timely manner if the value is less than 30)  
2. Connect one end of the USB charging cable to the Type-C charging input interface of the charging compartment, and the other end to the USB port of the power adapter. When charging the charging compartment, the display screen flashes with the number 100 indicating a fully charged state.  
3. When the left and right ears are low on battery, the earphones will prompt low battery. Please put the earphones into the charging compartment and close the lid to charge. The light pillars on both sides of the charging display screen flash for 5 seconds before turning off.

4. This product is not sold with an adapter. If consumers use a power adapter for charging, they should use a power adapter that meets the standard requirements.

5. When there are foreign objects and poor contact in the earphone charging port, please gently wipe and clean the earphone charging port with a cotton swab dipped in alcohol.

**Product parameters**

Product Name: Wireless Earphones. When there are foreign objects and poor contact in the earphone charging port, please gently wipe and clean the earphone charging port with a cotton swab dipped in alcohol  
Version: V5.4  
Bluetooth reception distance: about 10 meters (in an accessible environment)  
Battery Type: Polymer Lithium Ion Battery  
Earphone battery capacity: 35 mAh  
Earphone charging time: approximately 1.5H  
Charging compartment battery capacity 300mAh  
Charging time of charging compartment: about 2.5H  
Rated input of charging compartment: 5V-500mA  
Call duration: approximately 5H Play duration: approximately 6H (70% volume)  
Speaker size: 10mm in diameter  
Speaker impedance: 32 Ω  
Frequency response range: 20 Hz-20 kHz  
Execution standard: GB 4943.1-2022  
FCC ID: 2BNS3-NS22  
(Due to the small size of the product, the FCC ID number is located in the instruction manual and on the outer packaging)  
Support AAC and SBC high-quality audio decoding

**Warranty Policy**

1.Under normal operation and use, if a malfunction occurs without disassembly or repair, the product host will be replaced within seven days from the date of purchase and covered by a one-year warranty.  
2.When providing warranty, it is necessary to present the warranty card and valid purchase voucher. If lost, please contact our customer service department to inquire about the user information file.  
3. For products that are eligible for exchange, you can directly handle the exchange procedures with the agent,  
4. Please fill in and save the warranty card after purchasing the product.

**Non warranty regulations**

Any of the following situations will not be covered by warranty:

- Damage caused by human factors, including use in abnormal working environments and damage caused by not following the instructions;
- Improper storage: such as performance damage caused by prolonged exposure of the product to abnormal humidity and temperature environments;
- The user disassembles, repairs, modifies or repairs the device without authorization from our company's warranty unit;
- Damage caused by force majeure (such as floods, fires, earthquakes, lightning strikes, etc.);
- The product warranty card and purchase voucher do not match the product model or have been altered without authorization.

Product model	
Order Number	
user name	
Contact address and phone number	
Reason for warranty	



QUALIFIED  
CERTIFICATE

MODEL: \_\_\_\_\_  
CHECKER: \_\_\_\_\_  
DATE: \_\_\_\_\_

说明书：157g书写纸 四折页 正反印刷

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.—  
—Increase the separation between the equipment and receiver.—

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID:2BNS3-NS22