



成品尺寸: 60x85mm

80g书纸

单色印刷

风琴折

<p><b>TRUE WIRELESS STEREO</b> sanag J20S</p>  <p>User Guide</p>	<p><b>● product overview</b></p>  <p><b>● Key function operation</b></p> <ul style="list-style-type: none"><li>● Power on: 1. Open the charging compartment, remove the headphones, and the headphones will automatically turn on and pair. After successful pairing, the main ear light flashes slowly and the auxiliary ear light goes out; 2. Press and hold the MFB button for 3 seconds to manually turn on the device.</li><li>● Shutdown: Put the headphones into the charging compartment and close the cover to automatically shut off.</li><li>● Pairing: After the headphones are turned on, they automatically enter pairing mode (waiting to be connected to the phone), with the ice blue light on the main ear flashing slowly and the light on the secondary ear not turning on.</li><li>● Answer: When receiving an incoming call, simply click the MFB button on the left and right ears.</li><li>● Hang up: During a call, double-click the MFB button on both left and right ears.</li><li>● Reject: When receiving an incoming call, press and hold the MFB button for 2 seconds on either ear.</li><li>● Play/Pause: Click the MFB button on either side of the ear.</li><li>● Previous song: Double click the MFB button on the left ear.</li><li>● Next track: Double click the MFB button on the right ear.</li><li>● Volume increase: Three clicks on the MFB button on the left ear.</li><li>● Volume reduction: Three clicks on the right ear MFB button.</li><li>● Voice Assistant: Press and release the MFB key on the right ear four times to access the voice assistant.</li></ul> <p>Sleep mode: Press and hold any ear for 3 seconds to hear a prompt sound, then release to enter sleep mode. The volume will decrease by 30%, and the earphones will lose touch. After the earphones are stored, restart and resume normal operation.</p> <p>● Reset the earphones: When the phone is not connected and turned on, press any 5 MFB buttons on the left and right ears to reset the earphones to their factory settings. After a successful reset, the ice blue light will automatically turn off after 2 seconds.</p> <p>Game Mode/Music Mode: Four clicks on the MFB button on the left ear to enter low latency mode, and then four clicks again to switch to music mode.</p> <p>Low battery alarm: When the earphone battery is low, a low telegram alarm sound is prompted every 3 minutes.</p> <p>Charging: When the earphones are placed in the charging compartment and the compartment charges them, the ice blue light on the earphones will remain on for a long time. After being fully charged, the ice blue light on the earphones will turn off. When charging the charging case, the ice blue light in the charging case continuously flashes, and the ice blue light remains on when the charging case is fully charged.</p>	<p><b>● Bluetooth operation</b></p> <ul style="list-style-type: none"><li>● Bluetooth connection is successful:<ol style="list-style-type: none"><li>1. The headset enters Bluetooth mode, and the phone searches for the Bluetooth pairing name 'sanag J20S'. Click on the connection.</li><li>2. The headset connects to the device once by default.</li></ol></li><li>● Bluetooth disconnected:<ol style="list-style-type: none"><li>1. Manually turn off the Bluetooth of the mobile phone, and the headset enters Bluetooth pairing mode.</li><li>2. Disconnect the headset from the phone after overdistance, return to the effective distance range within 5 minutes, and connect the phone normally. After 5 minutes, it will automatically shut down.</li></ol></li></ul>		<p><b>● Specification parameters</b></p> <ul style="list-style-type: none"><li>● Name: TWS Bluetooth earphones</li><li>● Model: sanag J20S</li><li>● Bluetooth version: V5.4</li><li>● Connection range: <math>\geq 10m</math></li><li>● Earphone battery capacity: 35mAh</li><li>● Charging compartment battery capacity: 400mAh</li><li>● Input: 5V --- 1A</li><li>● FCC ID:2A6MS-J20SMAX</li></ul> <p><b>● Matters needing attention</b></p> <ul style="list-style-type: none"><li>● Do not use abrasive cleaning agents to clean this product.</li><li>● Do not allow this product to be heated or placed near a source of fire, such as a cooking stove.</li><li>● Do not expose this product to direct sunlight for an extended period of time.</li><li>● Do not dispose of this product in fire to avoid explosion.</li><li>● Do not attempt to disassemble this product for any modifications, as it does not contain any repair components.</li><li>● Do not use this product in the rain.</li><li>● If you do not intend to use this product for a long time, please store it in a dry environment and charge the headphones at least once a month to extend their lifespan and avoid extreme temperatures and dust.</li></ul>	<p><b>● FCC Warning</b></p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"><li>- Reorient or relocate the receiving antenna.</li><li>- Increase the separation between the equipment and receiver.</li><li>- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li><li>- Consult the dealer or an experienced radio/TV technician for help.</li></ul> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>
---	--	--	--	--	---