


3-In-1

Wireless Charger

Quick Start Guide



For 15W phone charging, please use the 30W PD charger included.


Package Contents



Charging Station



Quick Charger



Charging Cable



15W/10W/7.5W

For Phones That Support Wireless Charging



2.5W

For Watches That Support
Wireless Charging



3W

For Earbuds That Support
Wireless Charging

How to Use



 Phone Charging Area

 Watch Charging Area

 Earbuds Charging Area

Standby

(Auto Off After 10s)



White

Charging

(Auto Off After 10s)



Orange


FOD Alarm

(Foreign Object Detection)




Red


Charging With Cases




MagSafe Case




Ordinary Case



Metallic Design



Pocket Case




Uneven Surface



Flexible & Foldable



Folded Mode



Stand Mode



Expanded Mode

Troubleshooting for Charging Issues

Phone Not Charging Consistently

1. Make sure your phone case is a MagSafe case.
2. Unplug the charging adapter and plug it back in after a few seconds.

AirPods Not Charging

1. AirPods Pro 1-2 or AirPods 2-4 with MagSafe/Wireless cases are compatible.
2. AirPods 1-4 with Lightning/USB-C cases are not compatible.
3. Check your AirPods package or order to make sure your AirPods support wireless charging.

Watch Not Charging

1. Unplug the charging adapter and plug it back in after a few seconds.
2. Update watch software through Watch app on the Phone > General > Software Update.

Contact us for help: cs@ellexware.com

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.