



Instruction Manual

Product parameters

Name: LED FAN LIGHT
Model: LEC016R
Size: $\phi 54 \times H16\text{cm}$
Input voltage : 100-240V/50~60hz
Power: 43W
LED 18W 3000K-6500K
RGB max 4W
Speaker 3W
Motor DC 24V/24V



Packing List



Matters needing attention:

1. Non professionals are not allowed to install it on their own. It must be operated by qualified electricians according to the instructions and standards;
2. Ensure that the load-bearing capacity of the ceiling is at least twice the total weight of the fan lights to avoid the risk of falling;
3. This product is not suitable for outdoor use (such as balconies, canopies, etc.) to avoid short circuits caused by rainwater erosion;
4. When the fan light is running, please keep the surrounding area at least 50cm clear of obstacles to ensure air circulation.
5. For daily cleaning,you can use a damp cloth to wipe the surface without using corrosive chemicals.
6. The fan blades can also be disassembled directly, convenient for cleaning and storage.
7. In case of any accident, disconnect the power first, then ask an electrician to check and fix it.
8. The remote control requires AAA * 2 batteries, please bring your own


Installation diagram



①.Install fan blades



②.Fixed hanging board



③.Wire connection




④.Set screw

Installation and usage instructions

- Step 1: Before installation, be sure to cut off the power supply;
Step 2: Align the blade holes in sequence and secure the blades with screws, as shown in Figure ①;
Step 3: Loosen the screws on all four sides of the hanging board and fix it to the ceiling, as shown in Figure ②;
Step 4: Fix the input wire on the terminal block, as shown in Figure ③;
Step 5: Align the buckles around the lamp body, rotate the lamp body to lock it, and tighten the screws on the edge of the hanging plate, as shown in Figure ④;
Step 6: After installation, you can control the fan to work through the wall switch and remote control;
Step 7: After connecting your phone's Bluetooth and fan light, you can control music playback through your phone and remote control.

Remote Control



This device complies with part 15 of the FCC Rules.Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and(2)this device must accept any interference received, including interference that may cause undesired operation

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.