


Enjoy music anytime, anywhere




Music Glass

Product Feature  
\*Bluetooth music playback  
\*Support TF card  
\*FM radio

\*Charging time: 2-3 H  
\*Working hour: 4-6 H  
\*Working range: 10M  
\*Product Size: 149\*149\*178mm

\*U lach disk  
\*Aux line.  
\*RGB light.

Instruction of Buttons



1. Mode switching/long press TWS interconnection
2. Click on the previous track/long press to decrease Volume
3. power on/off/pause/play
4. Click on the next track/long press to increase Volume
5. Light switching
6. AUX port
7. TF card socket
8. DC5V socket
9. Indicator lights

#### Operating instructions

1. Bluetooth connection: After turning on the speaker, switch to Bluetooth mode and turn on your phone's Bluetooth or other devices. Search for the Bluetooth name and find "Glass5 mini". Click to connect and hear the prompt sound "ding dong". Afterwards, the connection was successful.
2. Light Switching: Click on the light switch, there are a total of 5 light modes.
3. Radio operation: Click on the mode to switch to FM, and then press the power button to automatically search for channels.
4. TWS Couplet: After turning on, press and hold until you hear a beep and the couplet is successful.
5. Charging prompt: insert the USB cable into the TYPE-C charging port. When the red light is on, it indicates charging, and when the red light is off, it indicates charging is complete.

#### Common problems and solutions

1. After playing for a long time, if the battery is low, the device will automatically shutdown. Please fully charge it before turning it back on.
2. Does the device not work well beyond the effective distance of the Bluetooth connection, or is there some malfunction there.
3. Unable to connect to Bluetooth. Is Bluetooth in searchable mode or can the speaker be restarted. There are too many Bluetooth devices around you, please turn off some of them.

#### Attention

1. Use this product under normal temperature environment.
2. Do not play in the wet environment.
3. Avoid the damage of falling.
4. Do not dismantle or repair the speaker by yourself.

5. Built-in battery, do not throw the speakers in the fire.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction